

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

## SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT - 1" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input checked="" type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER-		7. Unit Agreement Name
2. Name of Operator Atlantic Richfield Company		8. Farm or Lease Name B.C. Dickinson "B"
3. Address of Operator P. O. Box 1978, Roswell, New Mexico 88201		9. Well No. 2
4. Location of Well UNIT LETTER <u>D</u> <u>660</u> FEET FROM THE <u>North</u> LINE AND <u>660</u> FEET FROM THE <u>West</u> LINE, SECTION <u>12</u> TOWNSHIP <u>15-S</u> RANGE <u>37-E</u> NMPM.		10. Field and Pool, or Wildcat Denton-Wolfcamp
15. Elevation (Show whether DF, RT, GR, etc.) 3804' DF		12. County Lea

### 16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ENTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

This well was shut in on 2/1/68 due to non-commercial production rates.  
We now propose to P & A as follows:

- Shoot off and recover 7" casing from 6500-7000'.
- Set these cement plugs:  
40 sx in 7" casing from 9200-9300'  
40 sx in and out of 7" stub  
40 sx across 9-5/8" shoe @ 4726'  
20 sx in top of well

9#/gal gel mud will be used to spot plugs. 13-3/8" & 9-5/8" casing strings will remain intact. Dry hole marker will be installed and location cleared and levelled in accordance w/NMOCC regulations.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>P.D. Betcher</u>	TITLE <u>Dist. Drlg. Supervisor</u>	DATE <u>5/25/70</u>
APPROVED BY <u>[Signature]</u>	TITLE <u>SUPERVISOR DISTRICT</u>	DATE <u>MAY 28 1970</u>
CONDITIONS OF APPROVAL, IF ANY:		