

Submit 3 Copies
to Appropriate
District Office

State of New Mexico
Energy, Minerals and Natural Resources Department

Form C-103
Revised 1-1-89

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION
P.O. Box 2088
Santa Fe, New Mexico 87504-2088

WELL API NO.
5. Indicate Type of Lease STATE ☐ FEE ☒
6. State Oil & Gas Lease No.
7. Lease Name or Unit Agreement Name McClure "C"
8. Well No. 1
9. Pool name or Wildcat Denton Wolfcamp

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS)	
1. Type of Well: OIL WELL ☒ GAS WELL ☐ OTHER	
2. Name of Operator Lynx Petroleum Consultants, Inc.	
3. Address of Operator P. O. Box 1979, Hobbs, NM 88241	
4. Well Location Unit Letter <u>A</u> : <u>990</u> Feet From The <u>East</u> Line and <u>330</u> Feet From The <u>North</u> Line Section <u>14</u> Township <u>15S</u> Range <u>37E</u> NMPM <u>Lea</u> County	
10. Elevation (Show whether DF, RKB, RT, GR, etc.) 3803' GL	

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐
PULL OR ALTER CASING ☐
OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐
COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐
CASING TEST AND CEMENT JOB ☐
OTHER: ☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. CIBP @ 9000' w/35' cement on top.
2. Circulate hole with mud.
3. Cut and pull casing @ + 8050' (TOC @ 8110').
4. Spot 100' cement plug 50' inside to 50' above casing stub. Tag plug.
5. Spot 100' cement plug 6250-6150' (top of Glorietta).
6. Spot 100' plug at 9 5/8" casing shoe from 4790-4690'.
7. Spot 100' plug at top of salt 2100-2000'.
8. Perforate 9 5/8" casing at 390' and circulate cement to surface between 9 5/8" and 13 3/8" casing leaving 100' cement inside 9 5/8" casing.
9. Spot 10 sxs surface plug.
10. Install dry hole marker and clean location.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Mark Wilson TITLE President DATE 3/21/91

TYPE OR PRINT NAME _____ TELEPHONE NO. _____

(This space for State Use)

APPROVED BY _____ TITLE _____ DATE _____

CONDITIONS OF APPROVAL, IF ANY

