

Submit 3 Copies  
to Appropriate  
District Office

State of New Mexico  
Energy, Minerals and Natural Resources Department

Form C-103  
Revised 1-1-89

DISTRICT I  
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II  
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III  
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION

P.O. Box 2088  
Santa Fe, New Mexico 87504-2088

WELL API NO. <u>30-025-07260</u>
5. Indicate Type of Lease STATE <input type="checkbox"/> FEE <input checked="" type="checkbox"/>
6. State Oil & Gas Lease No.
7. Lease Name or Unit Agreement Name C. S. Stone
8. Well No. 1
9. Pool name or Wildcat Medicine Rock (Devonian)

SUNDRY NOTICES AND REPORTS ON WELLS  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A  
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"  
(FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER	2. Name of Operator Maralo, Inc.	3. Address of Operator P. O. Box 832, Midland, Texas 79702 0832	4. Well Location Unit Letter <u>G</u> : <u>1980</u> Feet From The <u>North</u> Line and <u>1980</u> Feet From The <u>East</u> Line Section <u>22</u> Township <u>15S</u> Range <u>38E</u> NMPM <u>Lea</u> County
10. Elevation (Show whether DF, RKB, RT, GR, etc.) 3722 GL			

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data			
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:		
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>		CASING TEST AND CEMENT JOB <input type="checkbox"/>	
OTHER: <input type="checkbox"/>		OTHER: <input type="checkbox"/>	

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103. Call NMOCC to notify of plugging.
1. RUPU. Pull 2 3/8" tbg out of Baker Lok-Set prk.. Circ. hole w/10# mud-laden fluid.
  2. RU Wireline. Set CIBP @ 12,067' Cap w/ 35' cement.
  3. Perforate squeeze holes at top of Wolfcamp @ 9215'.
  4. TIH w/tbg & cmt retainer (or packer). Set @ +/- 9165'. Pump 75 sx cmt to retainer and squeeze out holes.
  5. Shoot 4 squeeze holes @ top of Glorietta @ 6400'.
  6. TIH w/cmt retainer (or packer) & tbg to +/- 6350'. Set retainer. Squeeze perfs @ 6400' w/75 sx cmt.
  7. Shoot 4 squeeze holes @ 4930' (50' below 9 5/8" csg. shoe).
  8. TIH w/cmt retainer (or packer) & tbg to +/- 4830'. Squeeze perfs @ 4930' w/75 sx cmt. TOH w/ tbg.
  9. Shoot 4 squeeze holes @ 377' (50' below 13 3/8" csg. shoe).
  10. TIH w/cmt retainer (or packer) & tbg to 277'. Squeeze perfs @ 377' w/75 sx cmt.
  11. PU & spot 10 sx surface plug. Cut off wellhead, weld on plate & clean up location.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Brenda Coffman TITLE Agent DATE 7-17-92  
TYPE OR PRINT NAME Brenda Coffman TELEPHONE NO. 915 684-7441

(This space for State Use) Orig. Signed by Paul Kautz Geologist JUL 20 '92

APPROVED BY \_\_\_\_\_ DATE \_\_\_\_\_

CONDITIONS OF APPROVAL, IF ANY:  
THE COMMISSION MUST BE NOTIFIED 24 HOURS PRIOR TO THE BEGINNING OF PLUGGING OPERATIONS FOR THE CH-03 TO BE APPROVED.