

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease
State ☐ Fee ☒

5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator Atlantic Richfield Company	8. Farm or Lease Name C. S. Stone
3. Address of Operator P. O. Box 1710, Hobbs, New Mexico 88240	9. Well No. 2
4. Location of Well UNIT LETTER B, 660 FEET FROM THE North LINE AND 1980 FEET FROM THE East LINE, SECTION 22 TOWNSHIP 15S RANGE 38E NMPM.	10. Field and Pool, or Wildcat Medicine Rock Dev.
15. Elevation (Show whether DF, RT, GR, etc.) 3733' GR	12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐
TEMPORARILY ABANDON ☐
PULL OR ALTER CASING ☐
OTHER ☐

PLUG AND ABANDON ☒
CHANGE PLANS ☐
OTHER ☐

REMEDIAL WORK ☐
COMMENCE DRILLING OPNS. ☐
CASING TEST AND CEMENT JOBS ☐
OTHER ☐

ALTERING CASING ☐
PLUG AND ABANDONMENT ☐

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

TD 12,835', PBD 12,800'. Present perms 12,756-766' & 12,680-705'. Top of salt @ 2305'.
13-3/8" OD 45# csg set @ 334' & cmt'd w/400 sx to surface.
9-5/8" OD 36 & 40# csg set @ 4920' & cmt'd w/2100 sx to surface.
5-1/2" OD 17 & 20# csg set @ 12,835' & cmt'd w/1005 sx.
TOC @ 8200'.

The above well has been depleted beyond economic limits and no other recompletion potentials exist. Propose to P&A in the following manner:

1. Rig up, install BOP & POH w/completion assy.
2. Run 5 1/2" cmt retr on tbg & set @ 12,645'.
3. Cmt squeeze thru retr w/30 sx Cl C cont'g 4% gel & 8# salt/sk, pull up & spot 5 sx on top of retr.
4. Fill hole w/heavy mud.
5. Cut 5 1/2" OD csg from free pt @ approx 8000' & pull.
6. Spot 40 sx cmt (100' plug) across top of 5 1/2" OD csg stub @ 8000'.
7. Spot 40 sx cmt (100' plug) across Glorieta @ 6410'.
8. Spot 60 sx cmt (100' plug) across bottom of 9-5/8" OD csg shoe @ 4920'.
9. Spot 50 sx cmt (100' plug) across top of salt @ 2305' (50 sx below & 50 sx above.)
10. Spot 10 sx cmt @ surface & install regulation dry hole marker. Clean & level location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED 

TITLE Dist. Drlg. Supv.

DATE 8/26/75

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY: