

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	
7. Unit Agreement Name	
8. Farm or Lease Name	
Peoples Security Co.	
9. Well No.	
1	
10. Field and Pool, or Wildcat	
Garrett-San Andres	
12. County	
LEA	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>
2. Name of Operator
LEA COUNTY WATER COMPANY
3. Address of Operator
P. O. BOX 2070, HOBBS, NEW MEXICO 88240
4. Location of Well
UNIT LETTER L, 1980 FEET FROM THE S LINE AND 660 FEET FROM THE W LINE, SECTION 23 TOWNSHIP 16 S RANGE 38 E NMPM.
15. Elevation (Show whether DF, RT, GR, etc.)
16.

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Well Status:

10 3/4" Surface Csg. set at 287 Cemented to surface
7" Oil String set at 5311 Cemented w/150 sx.
6 3/4" Open Hole 5311 -- 5616

Abandonment Procedure:

Hole will be loaded with mud-laden fluid.

1. Set Cement plug from 5616 back up to 5200' w/100 sx.
2. Set Cement plug from 2000' back up to 1800' w/50 sx.
3. Set Cement plug in top of 7" Casing w/10 sx.
4. Dry hole marker will be installed

100' plug in & out of 10 3/4" shoe

24 hr. notice prior to setting plugs

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED [Signature] TITLE Supervisor DATE 4-10-72
APPROVED BY [Signature] TITLE SUPERVISOR DISTRICT I DATE APR 13 1972
CONDITIONS OF APPROVAL, IF ANY: