

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION
P.O. Box 2088
Santa Fe, New Mexico 87504-2088

WELL API NO. 30-025-08578
5. Indicate Type of Lease STATE <input type="checkbox"/> FEE <input checked="" type="checkbox"/>
6. State Oil & Gas Lease No.
7. Lease Name or Unit Agreement Name Simmons Witt ASL
8. Well No. 1
9. Pool name or Wildcat Townsend Morrow

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)	
1. Type of Well: OIL WELL <input type="checkbox"/> OAS WELL <input checked="" type="checkbox"/> OTHER	
2. Name of Operator YATES PETROLEUM CORPORATION	
3. Address of Operator 105 South 4th St., Artesia, NM 88210	
4. Well Location Unit Letter J : 2310 Feet From The South Line and 2080 Feet From The East Line Section 11 Township 16S Range 35E NMPM Lea County	
10. Elevation (Show whether DF, RKB, RT, GR, etc.) 3980' GR	

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
PLUG AND ABANDON <input checked="" type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>
OTHER: <input type="checkbox"/>	OTHER: <input type="checkbox"/>

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Morris Keith, Engineer for Yates Petroleum Corporation, received verbal permission from Gary Wink w/OCD-Hobbs, to plug and abandon well as follows:

1. TIH with open ended 2-7/8" tubing to 596' (50' inside 8-5/8" stub). Load hole with plugging mud.
2. Spot a 100 sack Class C + 2% CaCl2 cement plug from 596-450'. WOC 3 hours. Tag plug.
3. TIH with tubing. Set an 85 sack Class C + 2% CaCl2 cement plug from 413-313'. WOC 3 hours. Tag plug.
4. TIH with tubing. Set an 85 sack Class C + 2% CaCl2 cement plug from 250-150'.
5. Set a 45 sack Class C + 2% CaCl2 cement plug from 50' to surface.
6. Nipple down BOP's. Mix 50 sacks Class C cement into cellar.
7. Install regulation abandonment marker.

NOTIFY OCD-HOBBS (505-393-6161) 24 HOURS PRIOR TO COMMENCING PLUGGING OPERATIONS

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Rusty Klein TITLE Operations Technician DATE May 5, 1998
TYPE OR PRINT NAME Rusty Klein TELEPHONE NO. 505/748-1471

(This space for State Use)

ORIGINAL RECORDED BY CHRIS WILLIAMS
DISTRICT SUPERVISOR

APPROVED BY _____ TITLE _____ DATE _____

CONDITIONS OF APPROVAL, IF ANY: