

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease  
State  Fee

5. State Oil & Gas Lease No.  
**B-8944**

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <input type="checkbox"/>	7. Unit Agreement Name -----
2. Name of Operator <b>Skelly Oil Company</b>	8. Farm or Lease Name <b>Mexico "F"</b>
3. Address of Operator <b>P. O. Box 1351, Midland, Texas 79701</b>	9. Well No. <b>11</b>
4. Location of Well UNIT LETTER <b>B</b> <b>801</b> FEET FROM THE <b>North</b> LINE AND <b>1839</b> FEET FROM THE <b>East</b> LINE, SECTION <b>2</b> TOWNSHIP <b>15S</b> RANGE <b>37E</b> NMPM.	10. Field and Pool, or Wildcat <b>Denton Wolfcamp</b>
15. Elevation (Show whether DF, RT, GR, etc.) <b>3811' DF</b>	12. County <b>Lea</b>

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- 1) Move in plugging unit.
- 2) Set 5-1/2" cast iron bridge plug at 9100' and cap with cement to approximately 9075'.
- 3) Locate free point, cut off, and salvage approximately 6100' of 5-1/2" OD casing.
- 4) Spot 50 sack cement plug across top of 5-1/2" OD casing stub.
- 5) Spot 50 sack cement plug across bottom of 8-5/8" casing set at 4771'.
- 6) Spot 50 sack cement plug across top of salt section at 2273'.
- 7) Spot 10 sack cement plug from surface to 35'.
- 8) Set dry hole marker.

All intervals not cemented will be filled with 10# mud.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED (Signed) C. J. LOVE C. J. Love TITLE Dist. Production Manager DATE July 17, 1973

APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_ DATE \_\_\_\_\_

CONDITIONS OF APPROVAL, IF ANY: