

OIL CONSERVATION DIVISION

P. O. BOX 2088

SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-79

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S. O.S.	
LAND OFFICE	
OPERATOR	

1a. Indicate Type of Lease
State ☒ For ☐
5. State Oil & Gas Lease No.
K-33
7. Unit Agreement Name
8. Farm or Lease Name
State K-33
9. Well No.
1
10. Field and Prod. or Whdeat
Shoe Bar East Devonian
12. County
Lea

SUNDRY NOTICES AND REPORTS ON WELLS

DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO CEMENT OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE APPLICATION FOR PERMIT - "A" (FORM C-101) FOR SUCH PROPOSALS.

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐
2. Name of Operator
Jake L. Hamon
3. Address of Operator
611 Petroleum Building, Midland, Texas 79701
4. Location of Well
UNIT LETTER K 1980 FEET FROM THE South LINE AND 1980 FEET FROM THE West LINE, SECTION 30 TOWNSHIP 16S RANGE 36E NE1/4

15. Elevation (Show whether DF, RT, GR, etc.)
3943.3' K.B.

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK ☐	PLUG AND ABANDON ☒	REMEDIAL WORK ☐	ALTERING CASING ☐
TEMPORARILY ABANDON ☐	CHANGE PLANS ☐	COMMENCE DRILLING OPER. ☐	PLUG AND ABANDONMENT ☐
PULL OR ALTER CASING ☐	OTHER ☐	CASING TEST AND CEMENT JOBS ☐	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULES 1103.

1. Circulate hole with 10# mud and pull tubing out of hole.
2. Set bridge plug in 5-1/2" casing at 12,950' and dump 35' (4 sacks) of cement on plug.
3. Set cement plugs as following:
 - A. 100' (35 sacks) in and out of the 5-1/2" casing stub. Tag plug.
 - B. If the 5-1/2" casing is pulled below the top of the Glorieta Sand at 6,318', set a 100' (35 sack) cement plug at the top of the Glorieta.
 - C. 150' (60 sacks) in and out of the base of 9-5/8" casing from 4,240' back to 4,090'. Tag plug.
 - D. 100' (75 sacks) in and out of the 9-5/8" casing stub.
 - *E. 130' (100 sacks) in and out of the base of the 13-3/8" surface casing from 470' back to 340'. Tag plug.
 - F. 10' (10 sacks) in the top of the 13-3/8" casing and set a 4" OD permanent marker.

THE COMMISSION MUST BE NOTIFIED
24 HOURS PRIOR TO COMMENCING WORK

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Cecil N. Bunker TITLE Petroleum Engineer DATE 9-18-81APPROVED BY Les Clements TITLE Oil & Gas Insp. DATE SEP 21 1981

* 100' Plug at top of Salt if exposed