

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>		5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
2. Name of Operator K. K. AMINI		5. State Oil & Gas Lease No. L-4525
3. Address of Operator P. O. Drawer 3068, Midland, Texas 79701		7. Unit Agreement Name
4. Location of Well UNIT LETTER M 766 FEET FROM THE South LINE AND 554 FEET FROM THE West LINE, SECTION 35 TOWNSHIP 16S RANGE 34E NMPM.		8. Farm or Lease Name State Sale
15. Elevation (Show whether DF, RT, GR, etc.) 4068' RT		9. Well No. 1
		10. Field and Pool, or Wildcat Undesignated
		12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐
TEMPORARILY ABANDON ☐
PULL OR ALTER CASING ☐
OTHER ☐

PLUG AND ABANDON ☒
CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐
COMMENCE DRILLING OPNS. ☐
CASING TEST AND CEMENT JOB ☐
OTHER ☐

ALTERING CASING ☐
PLUG AND ABANDONMENT ☐

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

To Plug & Abandon Upon Approval -

- #1 - Pull 2 3/8" tubing.
- #2 - Set C.I.B.P. @ 8650' w/ 35' cement cap.
- #3 - Load hole w/ 9.5# laden fluid.
- #4 - Free point 4 1/2" csg.
- #5 - Cut and pull 4 1/2" csg. approx. 6000'.
- #6 - Run 2 3/8" tubing and spot 25 sk. plug on top of 4 1/2" csg. stub w/ 1/2 in and 1/2 out & 35 sks. @ San Andres approx. 4630'.
- #7 - Pull 2 3/8" tubing and spot 40 sk. plug in and out of 8 5/8" intermediate csg.
- #8 - Free point 8 5/8" csg.
- #9 - Cut & pull 8 5/8" csg. approx. 1100'.
- #10 - Run tubing spot 40 sk. plug on top of 8 5/8" stub w/ 1/2 in and 1/2 out.
- #11 - Spot 40 sk. plug in and out of 13 3/8" surface csg. 106' plug
- #12 - 10 sks. plug and marker in top of surface csg. and clean up location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED  TITLE Comptroller

DATE 11/18/75

APPROVED BY _____ TITLE _____ DATE _____
CONDITIONS OF APPROVAL, IF ANY: