

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. K-5711

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator Imperial-American Management Co.	8. Form or Lease Name Saunders State
3. Address of Operator 507 Midland Savings Bldg., Midland, Texas 79701	9. Well No. 1-Y
4. Location of Well UNIT LETTER <u>P</u> <u>990</u> FEET FROM THE <u>South</u> LINE AND <u>990</u> FEET FROM THE <u>East</u> LINE, SECTION <u>9</u> TOWNSHIP <u>15-S</u> RANGE <u>33-E</u> NMPM.	10. Field and Pool, or Wildcat Saunders Permo Penn
15. Elevation (Show whether DF, RT, GR, etc.) 4188' GR	12. County Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>
OTHER <input type="checkbox"/>	OTHER <input type="checkbox"/>
PLUG AND ABANDON <input checked="" type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

We propose to plug and abandon this well as follows:

1. Load hole w/9.5# mud.
2. Set 25 sx cement plug - 9275-9500' in 5½" csg.
3. Shoot off 5½" csg at free point, est. 7000', and pull same.
4. Set 30 sx cement plug from 4230-4330', half in - half out of 8-5/8" csg.
5. Shoot off 8-5/8" csg at free point, est. 2000' and pull same.
6. Set 100' cement plug at base of salt section, 2500-2600'.
7. Set 100' cement plug at top of salt section, 1500-1600'.
8. Set 75 sx cement plug from 300-400', half in - half out of 13-3/8" casing.
9. Set 15 sx cement plug from 0-20'.
10. Remove wellhead, weld plate over csg., set surface marker, clean location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>[Signature]</u>	TITLE <u>Division Manager</u>	DATE <u>3-18-71</u>
APPROVED BY <u>[Signature]</u>	TITLE <u>SUPERVISOR DISTRICT</u>	DATE <u>MAR 22 1971</u>
CONDITIONS OF APPROVAL, IF ANY:		

RECEIVED

MAR 1 - 1971

OIL CONSERVATION COMM.
40388. N. ...