

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. K-5481
7. Unit Agreement Name
8. Farm or Lease Name Nappi
9. Well No. 1
10. Field and Pool, or Wildcat Kemnitz, Lower Wolfcamp
12. County Lea

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT --" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>
2. Name of Operator John S. Goodrich
3. Address of Operator 2205 Wilco Building, Midland, Texas 79701
4. Location of Well UNIT LETTER <u>M</u> <u>660</u> FEET FROM THE <u>West</u> LINE AND <u>660</u> FEET FROM THE <u>South</u> LINE, SECTION <u>23</u> TOWNSHIP <u>16-S</u> RANGE <u>33-E</u> NMPM.
15. Elevation (Show whether DF, RT, GR, etc.) 4191.9 GR

16.

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐
TEMPORARILY ABANDON ☐
PULL OR ALTER CASING ☐
OTHER ☐

PLUG AND ABANDON ☒
CHANGE PLANS ☐
OTHER ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐
COMMENCE DRILLING OPNS. ☐
CASING TEST AND CEMENT JOB ☐
OTHER ☐

ALTERING CASING ☐
PLUG AND ABANDONMENT ☐
OTHER ☐

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

As soon as a rig becomes available it is the intention of operator to plug and abandon this well by performing the following operations:

- 1.) Set a Cast Iron Bridge Plug below 9400' in the 5-1/2" csg. that was set at 10,870' (the theoretical cement top is 9060')
- 2.) Cut and recover as much 5-1/2" csg. as possible.
- 3.) Place a 50 sx cmt plug at top of 5-1/2" csg. stub.
- 4.) Place a 50 sx cmt plug at top of Glorietta formation (5929').
- 5.) Place a 50 sx cmt plug at base of 8-5/8" csg. (4443').
- 6.) Cut and recover as much 8-5/8" csg. as possible.
- 7.) Place a 55 sx cmt plug at top of 8-5/8" csg. stub.
- 8.) Place a 75 sx cmt plug at base of 13-3/8" csg. (300').
- 9.) Place a 10 sx cmt plug at surface.
- 10.) Place a marker as required by State regulations.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED JS Goodrich TITLE Owner DATE 5-28-74

APPROVED BY _____ TITLE _____ DATE _____
CONDITIONS OF APPROVAL, IF ANY: