

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

7. Unit Agreement Name	
8. Farm or Lease Name Gantt	
9. Well No. 1	
10. Field and Pool, or Wildcat Undes. Shoebar North	
12. County Lea	

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- Dry
2. Name of Operator Manzano Oil Corporation (505-623-1996)
3. Address of Operator P.O. Box 571, Roswell, NM 88202
4. Location of Well UNIT LETTER P 555 FEET FROM THE South LINE AND 765 FEET FROM THE East LINE, SECTION 12 TOWNSHIP 16-S RANGE 35-E NMPM.
15. Elevation (Show whether DF, RT, GR, etc.) 3960' GR

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	
		OTHER <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1703.

Intend to plug and abandon according to instructions from Oil Conservation Division Hobbs office 8/14/85.
Set CIBP at 10,250' and cap with 35' cement. Perfs @ 10,292-302'.
Load hole with 10# salt gel.
Set the following plugs:
100' Top Abo 8270'
100' Glorietta 6220'
Intend to attempt to pull approximately 5000' of 5-1/2" casing.
Set 100' plug 50' in and out of stub and tag cement.
100' plug @ shoe of 8-5/8" 4160'
(50' in and out of shoe). Tag cement.
100' Top of Salt 1875'
100' inside 9-5/8" casing @ 350'.
10 sacks at surface. Install dry hole marker.
Will clean and level location in compliance with regulations.
Summary of plugs: 35' @ 11,250', 100' each @ 8270', 6220', 100' stub of 5-1/2" casing, 100' @ 4160', 1875' & 350'. 10 sacks @ surface.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED	TITLE Jackie Midkiff/Prod. Clerk	DATE 8/14/85
ORIGINAL SIGNED BY JERRY TEAGON	TITLE	DATE
APPROVED BY DISTRICT 1 SUPERVISOR	TITLE	DATE
CONDITIONS OF APPROVAL, IF ANY:		

AUG 19 1985

RECEIVED

AUG 16 1985

U.S. DEPT. OF JUSTICE
FEDERAL BUREAU OF INVESTIGATION