

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION
P.O. Box 2088
Santa Fe, New Mexico 87504-2088

WELL API NO. 30-025-25401
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No. 008074
7. Lease Name or Unit Agreement Name STATE 26
8. Well No. 1
9. Pool name or Wildcat KEMNITZ LOWER WOLFCAMP
10. Elevation (Show whether DF, RKB, RT, GR, etc.) RKB 4204

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>
2. Name of Operator W. A. MONCRIEF, JR.
3. Address of Operator MONCRIEF BUILDING, NINTH @ COMMERCE, FW, TX 76102

4. Well Location Unit Letter <u>E</u> : <u>661</u> Feet From The <u>WEST</u> Line and <u>1980</u> Feet From The <u>NORTH</u> Line Section <u>26</u> Township <u>16S</u> Range <u>33E</u> NMPM LEA County
--

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
OTHER: <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
	CASING TEST AND CEMENT JOB <input type="checkbox"/>
	OTHER: <input type="checkbox"/>

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. TOOH w/rods & tbg. Dump 35' cmt on top of RBP @ 10,874'.
2. Set CIBP @ 10,700'. Dump 35' cmt on top (Top perforations @ 10,770')
3. Pull stretch & cut 5 1/2" csg at free pipe point.
4. GIH w/tbg to top of csg. Set 30 sx plug 50' in & 50' out of csg & tag cmt.
5. Pull up to 7100' (if csg. cut is deeper) Set 35 sx plug.
6. Pull up to 5922' set 35 sx plug (Top of Glorietta)
7. Pull up to 4555' set 35 sx plug (8 5/8' csg. shoe at 4505')
8. Pull up to 1500' set 35 sx plug.
9. Set 10 sx plug at surface. Weld plate & dry hole marker.

Estimated starting date 5-1-94.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Patsy Holcomb TITLE Agent DATE 4/11/94
TYPE OR PRINT NAME PATSY HOLCOMB TELEPHONE NO. 817 336-7232

(This space for State Use)

ORIGINAL SIGNED BY JERRY SEXTON
DISTRICT I SUPERVISOR

APR 15 1994

APPROVED BY _____ TITLE _____ DATE _____
CONDITIONS OF APPROVAL, IF ANY: