

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATIONS	

OIL CONSERVATION DIVISION
P. O. BOX 2068
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-77

4a. Indicate Type of Lease
State ☒ Fee ☐
5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE APPLICATION FOR PERMIT - FORM C-101 FOR SUCH PROPOSALS.)

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐	7. Unit Agreement Name Saunders Reef
2. Name of Operator Santa Fe Energy Operating Partners, L.P.	8. Form of Lease Name State NM 2
3. Address of Operator 500 W. Illinois, Suite 500, Midland, TX 79701	9. Well No. 1
4. Location of Well UNIT LETTER M 660 FEET FROM THE South LINE AND 660 FEET FROM THE West LINE, SECTION 2 TOWNSHIP 15S RANGE 32E NMPM.	10. Field and Pool, or Whedat Sowell Morrow
11. Elevation (Show whether DF, RT, GR, etc.) 4291' DF	12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK ☐	PLUG AND ABANDON ☒	REMEDIAL WORK ☐	ALTERING CASING ☐
TEMPORARILY ABANDON ☐	CHANGE PLANS ☐	COMMENCE DRILLING OPS. ☐	PLUG AND ABANDONMENT ☐
PULL OR ALTER CASING ☐	OTHER ☐	CASING TEST AND CEMENT JOBS ☐	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Estimated plugging date: August, 1986. Place & tag 100' cmt plug @ 12,100'. Displace wellbore w/10# salt mud. Place 100' cmt plug across Atoka top @ 11,439'. Place 100' cmt plug across Wolfcamp top @ 8945'. Place 100' cmt plug across Abo top @ 7562'. Cut & pull 5 1/2" csg @ free point. Place & tag 100' cmt plug across csg stub. Place 100' cmt plug across Glorieta top @ 5451' if not covered by csg stub plug. Place & tag 100' cmt plug across 8 5/8" csg shoe @ 4120'. Place 100' cmt plug across salt top @ 1599'. Place & tag 100' cmt plug across 13 3/8" csg shoe @ 420'. Cut off wellhead 5' below ground level. Place 10 sx surface plug. Install P&A marker. Clean up & clear location.

ALL INFORMATION CONTAINED HEREIN IS TO BE USED FOR THE BEGINNING OF PLUGGING OPERATIONS FOR THE C-103 TO BE APPROVED.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED P. J. Gaume P. J. Gaume TITLE Sr. Production Engineer DATE 7/15/86
ORIGINAL SIGNED BY JERRY SEXTON
DISTRICT SUPERVISOR
APPROVED BY _____ TITLE _____ DATE SEP 8 1986
CONDITIONS OF APPROVAL, IF ANY: