

Submit 3 Copies
to Appropriate
District Office

State of New Mexico
Energy, Minerals and Natural Resources Department

Form C-103
Revised 1-1-89

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION

P.O. Box 2088
Santa Fe, New Mexico 87504-2088

WELL API NO.

30-025-27981

5. Indicate Type of Lease

STATE ☒

FEE ☐

6. State Oil & Gas Lease No.

V-173

7. Lease Name or Unit Agreement Name

Valentine VL State

8. Well No.

1

9. Pool name or Wildcat

Saunders Permo Upper Penn

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"
(FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:

OIL
WELL ☒

GAS
WELL ☐

OTHER

2. Name of Operator

YATES PETROLEUM CORPORATION

3. Address of Operator

105 South 4th St., Artesia, NM 88210

4. Well Location

Unit Letter K : 2310 Feet From The South Line and 1650 Feet From The West Line

Section 10

Township 15S

Range 33E

NMPM

Lea

County

10. Elevation (Show whether DF, RKB, RT, GR, etc.)

4188.4' GR

11.

Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐

PLUG AND ABANDON ☐

TEMPORARILY ABANDON ☐

CHANGE PLANS ☐

PULL OR ALTER CASING ☐

OTHER: Perforate & acidize additional ☒
Bough AB & Bough D zones

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐

COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐

CASING TEST AND CEMENT JOB ☐

OTHER: ☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Propose to remove RBP and 9412', locate and cement squeeze possible casing leak and perforate and acidize additional Bough AB and Bough D zones, acidize present perforations and put on pump. When depleted, propose to convert to SWD in Canyon Dolomite from 10170-10300'. Workover will be done as follows:

1. POOH w/rods, tubing and RBP. GIH w/tubing, packer and RBP and test casing.
2. If casing tests will proceed. If casing does not test, will find hole and repair before proceeding will work.
3. Perforate 9825-9866' (Bough AB) as follows: 9825, 26, 57, 58, 62, 63, 64, 65 & 9866' (1 SPF - 17 holes); Perforate 99421-9977' (Bough D) as follows: 9941, 42, 45, 50, 70, 71, 76 & 9977' (1 SPF - 8 holes).
4. RIH w/tubing, packer and RBP. Set RBP at 10030' and test. Spot 1 bbl 15% NEFE acid across perforations 9970-10014'. Pull packer to 9960'. Acidize perforations

CONTINUED NEXT PAGE

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE

Rusty Klein

TITLE

Production Clerk

DATE 5-14-93

TYPE OR PRINT NAME

Rusty Klein

TELEPHONE NO. 505/748-1471

(This space for State Use) ORIGINAL SIGNED BY JERRY SEXTON
DISTRICT I SUPERVISOR

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

MAY 19 1993

10-11-1993

RECEIVED
MAY 18 1993
OCD HOBBS OFFICE