

OIL CONSERVATION DIVISION

P. O. BOX 2088

SANTA FE, NEW MEXICO 87501

Form C-103  
Revised 10-1-78

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease  
State ☐ Fee ☒  
5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT - A" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator Robert M. Edsel, Inc.	8. Farm or Lease Name Scott
3. Address of Operator 1110 N. Big Spring, Midland, Texas 79701	9. Well No. 2
4. Location of Well UNIT LETTER <u>K</u> <u>2310</u> FEET FROM THE <u>South</u> LINE AND <u>1980</u> FEET FROM THE <u>West</u> LINE, SECTION <u>1</u> TOWNSHIP <u>15-S</u> RANGE <u>36-E</u> NMPM.	10. Field and Pool, or Wildcat Undesignated-Wolfcamp
15. Elevation (Show whether DF, RT, GR, etc.) 3874' GR	12. County Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Pull Tubing and packer out of hole.
2. Set CIBP @ 10,950', Dump 35' (4 sx) on top.
3. Take stretch and determine free point of 5 1/2" casing (Estimated @ 7900')
4. Pull and lay down 5 1/2" casing.
5. Spot cement plug 50' in and out of 5 1/2" stub.
6. Spot 50' in and out of 8 5/8" casing shoe.
7. Spot 100' plug 2100' to 2200' (Above salt section).
8. Spot 10' plug at surface.
9. Install surface marker.

100' PLUG AT TOP OF GUMIETH

FOR RECORDING AND INDEXING  
FILED IN THE OFFICE OF THE  
CLERK OF THE DISTRICT COURT  
AT SANTA FE, NEW MEXICO  
DATE 4-30-84

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Jerry Sexton TITLE Agent DATE 4-30-84

ORIGINAL SIGNED BY JERRY SEXTON  
DISTRICT I SUPERVISOR

APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_ DATE \_\_\_\_\_

CONDITIONS OF APPROVAL, IF ANY:

MAY 3 1984