

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.O.S.	
LAND OFFICE	
OPERATOR	

CONSERVATION DIVISION
P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-70

5a. Indicate Type of Lease
State ☐ Fee ☒
5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL ☒ WELL GAS ☐ WELL OTHER-	2. Name of Operator AMOCO PRODUCTION COMPANY	7. Unit Agreement Name
3. Address of Operator P. O. BOX 68 HOBBS, NEW MEXICO 88240	4. Location of Well UNIT LETTER <u>S</u> <u>1930</u> FEET FROM THE <u>South</u> LINE AND <u>1980</u> FEET FROM THE <u>West</u> LINE, SECTION <u>3</u> TOWNSHIP <u>16-S</u> RANGE <u>32-E</u> NMPM.	8. Farm or Lease Name <u>Anderson C</u> 9. Well No. <u>1</u>
15. Elevation (Show whether DF, RT, GR, etc.) <u>4321.7' GR</u>		10. Field and Pool, or Wildcat <u>Ind. Anderson Ranch Wolfcamp</u>
16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data		12. County <u>Lea</u>

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK ☐	PLUG AND ABANDON ☒	REMEDIAL WORK ☐	ALTERING CASING ☐
TEMPORARILY ABANDON ☐	CHANGE PLANS ☐	COMMENCE DRILLING OPNS. ☐	PLUG AND ABANDONMENT ☐
PULL OR ALTER CASING ☐	OTHER ☐	CASING TEST AND CEMENT JOBS ☐	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Propose to Plug and Abandon the subject well as follows:
MISU. Release packer and RIH with tubing and packer. RIH w/ CIBP and set at 9850'. Cap w/ 25' of class H neat cement. Spot 50 BBLs of 10# brine w/ 25# gel/BBL. Pull up to 7700' and spot 25 SX class H ^{Neat} cement from 7700'-7500' (Top of Abo). Spot 40 BBLs brine gel. Pull up to 5800' and spot 25 SX class H neat from 5800'-5600' (top of Gloria at 5707'). Spot 30 BBLs brine gel. Pull up to 4250' and spot 25 SX class H neat from 4250'-4050' (8 3/8" CSG shoe @ 4150'). Spot 37 BBLs brine gel. Pull up to 2600' and spot 25 SX class H neat from 2600'-2400' (Top of Gates at 2500'). Spot 45 BBLs gel brine. Pull up to 520' and spot 25 SX class H neat from 520'-320' (13 3/8" CSG shoe at 420'). Spot 6 BBLs gel brine. Pull up to 80' and spot a 10 SX class H Neat plug to surface. Capwell and erect abandonment marker. MISU.

0+5 NMOC-D-H1-JRB 1-FJN 1-CMH

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>Charles M. Herring</u> <u>Eddie W. Seay</u> Oil & Gas Inspector	TITLE <u>ADMINISTRATIVE ANALYST (SG)</u>	DATE <u>12/9/85</u>
APPROVED BY _____	TITLE _____	DATE <u>DEC 11 1985</u>

CONDITIONS OF APPROVAL, IF ANY:

RECEIVED

DEC 10 1985

C.C.D.
HOBBS OFFICE