

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

OIL CONSERVATION DIVISION

P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

OIL WELL ☒ GAS WELL ☐ OTHER ☐

1. Name of Operator
Harben-Davis

2. Address of Operator
816 First National Bank Bldg. Midland, Texas 79701

3. Location of Well
UNIT LETTER M 145 FEET FROM THE West LINE AND 990 FEET FROM
THE South LINE, SECTION 22 TOWNSHIP 16N RANGE 38E NMPM.

15. Elevation (Show whether DF, RT, GR, etc.)
37131.1 GR

7. Unit Agreement Name
8. Farm or Lease Name <u>Cantina</u>
9. Well No. <u>1</u>
10. Field and Pool, or Wildcat <u>Wildcat</u>
12. County <u>Lea</u>

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>
OTHER <u>Operation Completion</u> <input type="checkbox"/>	OTHER <input type="checkbox"/>
PLUG AND ABANDON <input checked="" type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Tested San Andres after fracture treatment. Swabbed load followed by diminishing amounts of water with small oil cut. Prepared to P & A.
Plan to dump 35' Class C cement on CIBP and 5530'. Set CIBP @ 5200' with 50' Class C cement above, spotted with tubing. Cut and pull approximately 4000' of 5 1/2" casing. Load hole with 9.5# mud. Spot 100' cement at cross cut point. Tag cement top with tubing. Spot 100' cement across top of salt (2230'). Spot 10 sax of cement at surface. Leave casing stub 4' below ground surface of plowed and irrigated field. Fill cellar, remove caliche pad and pits. Leave surface restored for farming operations. Intermediate casing stub may be found with metal detector.

8. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED R. D. Guenther TITLE Agent DATE 7/1/85

APPROVED BY ORIGINAL SIGNED BY JERRY SEXTON TITLE DISTRICT 1 SUPERVISOR DATE JUL - 3 1985

CONDITIONS OF APPROVAL, IF ANY:

RECEIVED

JUL - 2 1985

61-30
HOBBS OFFICE