

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION
P.O. Box 2088
Santa Fe, New Mexico 87504-2088

WELL API NO. <u>30-025-30257</u>
5. Indicate Type of Lease STATE ☒ FEE ☐
6. State Oil & Gas Lease No. <u>B-4683</u>
7. Lease Name or Unit Agreement Name <u>Anderson Ranch Unit</u>
8. Well No. <u>22</u>
9. Pool name or Wildcat <u>Anderson Ranch Wolfcamp</u>

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)	
1. Type of Well: OIL WELL ☒ GAS WELL ☐ OTHER ☐	
2. Name of Operator Conoco Inc.	
3. Address of Operator P. O. Box 460 - Hobbs, NM 88240	
4. Well Location Unit Letter <u>U</u> : <u>660</u> Feet From The <u>south</u> Line and <u>660</u> Feet From The <u>west</u> Line Section <u>2</u> Township <u>16S</u> Range <u>32E</u> NMPM <u>Lea</u> County	
10. Elevation (Show whether DF, RKB, RT, GR, etc.)	

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK ☐	REMEDIAL WORK ☐
TEMPORARILY ABANDON ☐	ALTERING CASING ☐
PULL OR ALTER CASING ☐	COMMENCE DRILLING OPNS. ☐
OTHER: <u>Perf, Acidize & test add Wolfcamp</u> ☒	PLUG AND ABANDONMENT ☐
	CASING TEST AND CEMENT JOB ☐
	OTHER: ☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. MISC. Kill well if necessary w/ 2% KCL TFW. POOH w/ rods, pump & Hg.

2. Clean out to 9950'. Circ clean w/ 2% KCL. Pickle Hg. pump 25 bbls 15% HCL-NE-FE, displace w/ 32 bbls 2% KCL. Soak 30 mins, reverse out 2% KCL. Swab FH to 7200'. Spot 3 bbls 15% HCL-NE-FE acid from 9930' - 9798'. POOH.

3. Perf Wolfcamp. Log w/ CCH from 9950' - minimum 10 footage. Perf from 9926' - 9856' w/ 4 spf & POOH. Set RBP at 9940' & pk at 9745'. Swab well.

4. Acidize 9798' - 9930' w/ 135 bbls 15% HCL-NE-FE & 700 # graded rock salt in 3 equal stages. Flush w/ 67 bbls 2% KCL TFW. Swab well. Isolate Lower Wolfcamp perms. Release pk at 9745' & retrieve RBP at 9940'. Set RBP at 9900' & pk at 9745'. Acidize perms 9798' - 9887' w/ 114 bbls 15% HCL-NE-FE & 560 # graded rock salt in 3 equal stages. Flush w/ 66 bbls 2% KCL. Swab well. For further info call 397-5869

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Daphne Simpson TITLE Administrative Supervisor DATE January 25, 1989

TYPE OR PRINT NAME D. F. Finney TELEPHONE NO. (505) 397-5800

(This space for State Use)

ORIGINAL SIGNED BY JERRY SEXTON

APPROVED BY D. F. Finney DISTRICT I SUPERVISOR TITLE _____ DATE JAN 30 1989

CONDITIONS OF APPROVAL, IF ANY:

NMOCO-Hobbs(3) File

RECEIVED

JAN 27 1989

**OCD
HOBBS OFFICE**