

Submit 3 Copies
to Appropriate
District Office

State of New Mexico
Energy, Minerals and Natural Resources Department

Form C-103
Revised 1-1-89

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION

P.O. Box 2088
Santa Fe, New Mexico 87504-2088

WELL API NO.

30-025-30398

5. Indicate Type of Lease

STATE ☒

FEE ☐

6. State Oil & Gas Lease No.

V-148

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"
(FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:

OIL
WELL ☒

GAS
WELL ☐

OTHER

2. Name of Operator

Nearburg Producing Co.

3. Address of Operator

P.O. Box 831 Hobbs NM 88260

4. Well Location

Unit Letter P : 400 Feet From The South Line and 400 Feet From The East Line

Section 24

Township

16

Range

36

NMPM

Lea County

10. Elevation (Show whether DF, RKB, RT, GR, etc.)

3840.7 GL

3855.7 RKB

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐

PLUG AND ABANDON ☒

TEMPORARILY ABANDON ☐

CHANGE PLANS ☐

PULL OR ALTER CASING ☐

OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐

ALTERING CASING ☐

COMMENCE DRILLING OPNS. ☐

PLUG AND ABANDONMENT ☐

CASING TEST AND CEMENT JOB ☐

OTHER: ☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Set CIBP at 10,115', cap w/35' cmt.
2. Pull csg free point, shoot off csg in free pipe (approx 6000').
3. GIH w/ tubing to 10,080'. Cir hole w/9# Brine w/25sx gel per 100 bbls.
4. PUH and set 25sx cmt plug (50' in and 50' out) of 4-1/2" csg stub.(Tag)
5. PUH and set 35sx cmt plug from 6100' to 6200'. (Base of San Andres)
6. PUH and set 35sx cmt plug (50' in and 50' out of 8-5/8" csg shoe).
7. PUH and set 35sx cmt plug from 2070' to 2170'. (Anhydrite)
8. Cut 10" 3000 psi well head off, set 10sx cmt for surface plug.
9. Install 4' dry hole marker with well legals.
10. Clean location, cut anchors off 1' below ground level.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE

TITLE

Completion Sup.

DATE

3-3-92

TYPE OR PRINT NAME

Tommy Willyard

TELEPHONE NO. 397-4186

(This space for State Use)

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

MAR 04 '92

RECEIVED

MAR 08 1992

OCD HOBBS OFFICE