

Submit 3 Copies
to Appropriate
District Office

State of New Mexico
Energy, Minerals and Natural Resources Department

Form C-103
Revised 1-1-89

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION
P.O. Box 2088
Santa Fe, New Mexico 87504-2088

| |
|---|
| WELL API NO. 30-025-33931 |
| 5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/> |
| 6. State Oil & Gas Lease No. VA-605 |
| 7. Lease Name or Unit Agreement Name Brunson AQK State Com |
| 8. Well No. 1 |
| 9. Pool name or Wildcat Wildcat Atoka |

| | |
|--|--|
| SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.) | |
| 1. Type of Well: OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER | |
| 2. Name of Operator YATES PETROLEUM CORPORATION | |
| 3. Address of Operator 105 South 4th St., Artesia, NM 88210 | |
| 4. Well Location Unit Letter <u>G</u> : <u>2260</u> Feet From The <u>North</u> Line and <u>1795</u> Feet From The <u>East</u> Line Section <u>10</u> Township <u>16S</u> Range <u>35E</u> NMPM Lea County 10. Elevation (Show whether DF, RKB, RT, GR, etc.) <u>4003' GR</u> | |

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☐
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐
PULL OR ALTER CASING ☐
OTHER: Add perfs in Atoka ☒

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐
COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐
CASING TEST AND CEMENT JOB ☐
OTHER: ☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Morris Keith, Engineer for Yates Petroleum Corporation received verbal permission from Chris Williams w/OCD-Hobbs to add perforations in the Atoka as follows:

1. Nipple down wellhead and nipple up BOP. TOOH with tubing and packer.
2. TIH with RBP and packer. Set RBP at 11950' and packer at 11850'. Test RBP to 5000 psi for 15 minutes. Spot 12' of 20-40 frac sand on top of RBP. TOOH with packer and tubing.
3. Perforate 11702-11734' with 76 holes, acidize & frac as necessary.
4. Flow test.
5. Pull RBP at 11950'.
6. Set packer with profile nipple and on/off assembly at 11650'. Return well to production.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Rusty Klein TITLE Operations Technician DATE April 13, 1998
TYPE OR PRINT NAME Rusty Klein TELEPHONE NO. 505/748-1471

(This space for State Use)

ORIGINAL NOTED BY CHRIS WILLIAMS
DISTRICT SUPERVISOR

APR 16 1998

APPROVED BY _____ TITLE _____ DATE _____

CONDITIONS OF APPROVAL, IF ANY: