

DISTRICT II

1301 W. Grand Avenue, Artesia NM 88210

DISTRICT III

1000 Rio Brazos Rd., Aztec NM 87410

DISTRICT IV

1220 S. St. Francis Dr., Santa Fe, NM 87505

State of New Mexico
Energy, Minerals and Natural Resources

OIL CONSERVATION DIVISION
1220 South St. Francis Dr.
Santa Fe, New Mexico 87504-2088

Form C-103
Revised March 25, 1999

WELL API NO. 30-025-34908
5. Indicate Type of Lease STATE <input type="checkbox"/> FEE <input checked="" type="checkbox"/>
6. State Oil & Gas Lease No.
7. Lease Name or Unit Agreement Name Big Bear ATN
8. Well No. 1
9. Pool Name or Wildcat Townsend Permo Upper Penn

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:
Oil Well ☒ Gas Well ☐ Other ☐

2. Name of Operator
Yates Petroleum Corporation

3. Address of Operator
105 South 4th Str., Artesia, NM 88210

4. Well Location
Unit Letter I : 1980 feet from the South line and 1120 feet from the East line
Section 29 Township 15S Range 35E NMPM County Lea

10. Elevation (Show whether DF, RKB, RT, GR, etc.)
4001' GR

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	MULTIPLE COMPLETION <input type="checkbox"/>
OTHER: <input type="checkbox"/>	

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
CASING TEST AND CEMENT JOB <input type="checkbox"/>	
OTHER: <input type="checkbox"/>	

12. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompilation.

Propose to plug and abandon as follows:

- 1) Set CIBP @ 10900' and cap w/35' cement.
- 2) Free point 5-1/2" casing. Cut and pull casing (Estimated recovery = 10000'). Load hole w/mud.
- 3) Spot 100' plug (minimum 25 sx) 1/2 in and 1/2 out of stub. WOC and tag plug.
- 4) Spot 100' plug across Abo top 8010-7910'.
- 5) Spot 100' plug across Glorieta top 6125-6025'.
- 6) Spot 100' plug 4745-4645'. — TAG (CSG. SHOE PLUG)
- 7) Spot 100' plug 2470-2370'.
- 8) Spot 100' plug 1917-1817'.
- 9) Spot 100' plug 452-352'. — TAG (SURF. SHOE PLUG)
- 10) Spot plug 60' to surface.

I hereby certify that the information above is a true and complete to the best of my knowledge and belief.

SIGNATURE Stormi Davis TITLE Regulatory Compliance Technician DATE 2/27/03

Type or print name Stormi Davis

Telephone No. 505-748-1471

(This space for State use)

APPROVED BY

Conditions of approval, if any:

ORIGINAL SIGNED BY
GARY W. WINK

OC FIELD REPRESENTATIVE II/STAFF MANAGER

DATE

2/27/03