

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

3d. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
B-2516	

SUNDRY NOTICES AND REPORTS ON WELLS  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER: Water Injection		7. Unit Agreement Name SMGSAU
2. Name of Operator Cities Service Company		8. Farm or Lease Name Tract 6
3. Address of Operator P. O. Box 1919, Midland, Texas 79702		9. Well No. 2
4. Location of Well UNIT LETTER N 660 FEET FROM THE South LINE AND 1980 FEET FROM THE West LINE, SECTION 29 TOWNSHIP 17S RANGE 33E NMPM.		10. Field and Pool, or Wildcat Maljamar (G-SA)
15. Elevation (Show whether DF, RT, GR, etc.) 4046' GR		12. County Lea

16.

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

O.T.D. 4312' sand, PBTD 2162'. It is proposed to plug and abandon this well in the following manner:

1. Perforate 2 squeeze holes @ approx. 2100'. Set a retainer @ approx. 2000' and squeeze w/150 sacks of class C w/2% CaCl<sub>2</sub> cement. Pull out of retainer and dump 100' of cement on top of retainer.
2. Perforate 2 squeeze holes @ approx. 1300'. Set a retainer @ approx. 1200' and squeeze w/100 sacks of class C w/2% CaCl<sub>2</sub> cement. Pull out of retainer and dump 100' of cement on top of retainer.
3. Perforate 2 squeeze holes @ approx. 500'. Set a retainer @ approx. 400' and squeeze w/50 sacks of class C cement. Pull out of retainer and circulate cement to surface.
4. Install a 4" dry hole marker to designate a plugged and abandoned location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>Elmer Startz</u>	TITLE <u>Reg Opr. Mgr.-Prod.</u>	DATE <u>1-14-82</u>
Orig. Signed By Jerry Sexton Dist. 1, Santa Fe		
APPROVED BY _____	TITLE _____	DATE _____
CONDITIONS OF APPROVAL, IF ANY:		