

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
B-1356	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <input type="checkbox"/>		7. Unit Agreement Name
2. Name of Operator Koch Exploration Company		8. Farm or Lease Name Miller State
3. Address of Operator P.O. Box 2256, Wichita, Kansas 67201		9. Well No. 2
4. Location of Well UNIT LETTER <u>0</u> <u>660</u> FEET FROM THE <u>South</u> LINE AND <u>1980</u> FEET FROM THE <u>East</u> LINE, SECTION <u>4</u> TOWNSHIP <u>17S</u> RANGE <u>34E</u> NMPM.		10. Field and Pool, or Wildcat Vacuum/Grayburg-SA
15. Elevation (Show whether DF, RT, GR, etc.) 4080 Gr.		12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <u>Current Status T.A.</u> <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1703.

Upon approval of this C-103, we propose to P & A the subject well in the following way:

1. Pump 25 sx cmt down tbq into open hole, leaving 35' of cmt above O.H.
2. Cut tbq off & pull same.
3. Cut 5-1/2" csg off & pull same.
4. 100' plug in & out of 5-1/2" stub.
5. 100' plug top of salt.
6. 100' plug in & out 8-5/8" surf csg.
7. 10 sx plugs @ surf w/marker.
8. Mud between plugs.
9. 24 hr notice given NMOCC prior to setting bottom plug.

WELL DATA:

1. 8-5/8" surf csg set @ 1520' C/W 472 sx.
2. 5-1/2" set @ 4680' C/W 100 sx.
3. O.H. 4680-4735'.
4. Well appears to have collapsed csg & tbq @ approx 3600'.

Expires 11/1/77

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED James D. Love TITLE Assistant Operations Mgr. DATE July 1, 1976

APPROVED BY John R. Love TITLE Assistant Operations Mgr. DATE July 1, 1976

CONDITIONS OF APPROVAL, IF ANY: