

2. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. 8-1520
7. Unit Agreement Name
8. Farm or Lease Name Bridges State
9. Well No. 78
10. Field and Pool, or Wildcat Vacuum Grayburg SA
12. County Lea

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- WIW
2. Name of Operator Mobil Oil Corporation
3. Address of Operator P. O. Box 633, Midland, TX 79701
4. Location of Well UNIT LETTER K , 1980 FEET FROM THE West LINE AND 1980 FEET FROM THE South LINE, SECTION 11 TOWNSHIP 17-S RANGE 34-E NMPM.
15. Elevation (Show whether DF, RT, GR, etc.) 4048 GR

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK	<input type="checkbox"/>
TEMPORARILY ABANDON	<input type="checkbox"/>
PULL OR ALTER CASING	<input type="checkbox"/>
OTHER	

PLUG AND ABANDON	<input checked="" type="checkbox"/>
CHANGE PLANS	<input type="checkbox"/>
OTHER	

SUBSEQUENT REPORT OF:

REMEDIAL WORK	<input type="checkbox"/>
COMMENCE DRILLING OPNS.	<input type="checkbox"/>
CASING TEST AND CEMENT JOB	<input type="checkbox"/>
OTHER	
ALTERING CASING	<input type="checkbox"/>
PLUG AND ABANDONMENT	<input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Pull injection tubing and packer @ 4588'.
2. Run 5-1/2" cement retainer on workstring and set @ 4600'+.
3. Squeeze San Andres open hole (4675'-4750') w/100sx Class "H" neat cement.
4. Pull out of retainer and spot 5 sx Class "H" neat cement on top of retainer.
5. Load hole with 9.5#/gal. brine.
6. Pull workstring to 1730'+ and spot 15 sx Class "H" neat cement.
7. Pull workstring.
8. Set 10 sx surface plug with Class "H" neat cement.
9. Erect monument and clear location.

THE COMMISSION MUST BE NOTIFIED 24 HOURS PRIOR TO THE BEGINNING OF PLUGGING OPERATIONS FOR THE C-103 TO BE APPROVED.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED *J. J. McDaniel* TITLE **Authorized Agent** DATE **7/29/76**

APPROVED BY _____ TITLE _____ DATE _____
CONDITIONS OF APPROVAL, IF ANY: