

NEW MEXICO OIL CONSERVATION COMMISSION

AUG 19 11 41 AM '65

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
E-9263	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input checked="" type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER		7. Unit Agreement Name
2. Name of Operator The Atlantic Refining Company		8. Farm or Lease Name State "AJ"
3. Address of Operator P. O. Box 1978, Roswell, New Mexico		9. Well No. 1
4. Location of Well UNIT LETTER <u>D</u> <u>660</u> FEET FROM THE <u>North</u> LINE AND <u>661.5</u> FEET FROM THE <u>West</u> LINE, SECTION <u>17</u> TOWNSHIP <u>18-S</u> RANGE <u>34-1</u> N.M.P.M.		10. Field and Pool, or Wildcat LA-queen
15. Elevation (Show whether DF, RT, GR, etc.) 4080' RT		12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

This well was temporarily abandoned in 1962 pending possible secondary recovery operations. We now propose to salvage casing and plug and abandon this well as follows:

Set 15 sx (105') cement plug in 5-1/2" casing 4350-4450.  
Shoot off and recover 5-1/2" casing as deep as possible.  
(Top of cement at 2170')  
Put 25 sx cement 1/2 in and 1/2 out of 5-1/2" casing stub.  
Put 25 sk cement plug across anhydrite top (1782') if this is above 5-1/2" stub.  
Put 25 sx cement in bottom of 8-5/8" surface casing at 256'.  
10 sx in top of well.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED [Signature] TITLE District Drilling Supervisor DATE 8-18-65

APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_ DATE \_\_\_\_\_

CONDITIONS OF APPROVAL, IF ANY: