

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
1065	

## SUNDRY NOTICES AND REPORTS ON WELLS

DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>		7. Unit Agreement Name
2. Name of Operator Marathon Oil Co.		8. Farm or Lease Name State EK "A"
3. Address of Operator P. O. Box 2409 Hobbs, N. M. 88240		9. Well No. 2
4. Location of Well UNIT LETTER <u>B</u> <u>660</u> FEET FROM THE <u>North</u> LINE AND <u>1980</u> FEET FROM THE <u>East</u> LINE, SECTION <u>18</u> TOWNSHIP <u>18-S</u> RANGE <u>34 E</u> N.M.P.M.		10. Field and Pool, or Wildcat EK Queen
15. Elevation (Show whether DF, RT, GR, etc.) 4078 GR		12. County Lea

## Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

### NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐  
TEMPORARILY ABANDON ☐  
PULL OR ALTER CASING ☒  
OTHER ☐

PLUG AND ABANDON ☒  
CHANGE PLANS ☐  
OTHER ☐

### SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐  
COMMENCE DRILLING OPNS. ☐  
CASING TEST AND CEMENT JOB ☐  
OTHER ☐  
ALTERING CASING ☐  
PLUG AND ABANDONMENT ☐

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Well is presently shut in with PBTD at 4450' and Queen perms 4430'-4440'

Plan to:

1. Set cement retainer at 4350'
2. Abandon perms with 40 sacks cement below and cap with 10 sacks above
3. Cut off 7" casing at 3100'
4. Place plug at top of 7" pipe with 25 sacks cement in and 25 sacks out
5. Place plug at bottom of 10 3/4" pipe(348') with 25 sacks cement in and 25 sacks out
6. Spot 10 sacks back to the surface of the 10 3/4" pipe
7. Cut off pipe 3' below surface and weld on plate
8. Erect marker and clean up location.

All plugs will be separated by mud-laden fluid

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED C. A. Niles TITLE Operations Superintendant DATE 6/20/74

APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_ DATE \_\_\_\_\_  
CONDITIONS OF APPROVAL, IF ANY: