

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form O-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

3. Indicate Type of Lease
State ☒ Fee ☐

5. State Oil & Gas Lease No.
E-2519-2

SUNDRY NOTICES AND REPORTS ON WELLS

DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" FORM C-101 FOR SUCH PROPOSALS.

1. ☐ OIL WELL ☐ GAS WELL ☒ OTHER <u>Injection Well Shut-in</u>	7. Unit Agreement Name
2. Name of Operator <u>Conoco Inc.</u>	8. Farm or Lease Name <u>East EK Unit</u>
3. Address of Operator <u>P.O. Box 460, Hobbs, NM 88240</u>	9. Well No. <u>4</u>
4. Location of Well UNIT LETTER <u>N</u> <u>330</u> FEET FROM THE <u>South</u> LINE AND <u>1980</u> FEET FROM THE <u>West</u> LINE, SECTION <u>22</u> TOWNSHIP <u>18S</u> RANGE <u>34E</u> NMPM.	10. Field and Pool, or Wildcat <u>EK Queen East</u>
15. Elevation (Show whether DF, RT, GR, etc.)	12. County <u>Lea</u>

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK ☐	PLUG AND ABANDON ☒	REMEDIAL WORK ☐	ALTERING CASING ☐
TEMPORARILY ABANDON ☐	CHANGE PLANS ☐	COMMENCE OR LING OPNS. ☐	PLUG AND ABANDONMENT ☐
PULL OR ALTER CASING ☐	OTHER ☐	CASING TEST AND CEMENT JOB ☐	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work, SEE RULE 1103.)

1. MIRD, pull CIBP up to 4500' and set, test CIBP to 600 psi
2. Spot 25 sacks of cement on top of CIBP to 4259', spot a cement plug from 1958'-1858' (10.4 sx ±)
3. Spot 2 bbls of 10% acetic acid from 501'-419', 4 JSPF, perforate @ 501'
4. If circulation is established, circulate 120 sacks through perfs @ 501' (37 sx should circulate to surface), NOC 1/2 - 1 hr.
5. If TDC is below 401', fill to 5-1/2" casing to 401' with cement.
6. If circulation cannot be established, spot a 100' cement plug from 501'-401' (10.4 sx ±), fill to surface with cement. Spot a 100' cement plug from 100'-0' (10.4 sx), cut casing 3' below restored ground level.
7. Erect a permanent P&A marker
8. Clean location, rig down
9. A P&A sketch is attached.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED [Signature] TITLE Administrative Supervisor DATE 8-6-86

ORIGINAL SIGNED BY JERRY SEXTON
DISTRICT I SUPERVISOR

APPROVED BY _____ TITLE _____ DATE AUG 11 1986

