

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. E-1532
7. Unit Agreement Name
8. Farm or Lease Name Lea 401 State
9. Well No. 2
10. Field and Pool, or Wildcat So. Vacuum-Wolfcamp
12. County Lea

SUNDY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>
2. Name of Operator Atlantic Richfield Company
3. Address of Operator P. O. Box 1976, Roswell, New Mexico 88201
4. Location of Well UNIT LETTER <u>A</u> <u>660</u> FEET FROM THE <u>North</u> LINE AND <u>660</u> FEET FROM THE <u>East</u> LINE, SECTION <u>21</u> TOWNSHIP <u>18-S</u> RANGE <u>35-E</u> NMPM.
15. Elevation (Show whether DF, RT, GR, etc.) 3908' GR

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>
OTHER <input type="checkbox"/>	OTHER <input type="checkbox"/>
PLUG AND ABANDON <input checked="" type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates including estimated date of starting any proposed work) SEE RULE 1103.

Oil production has declined to 1 BOPD & 100 BWPB. No remedial possibilities exist. We propose to P & A as follows:

Set 7" 29# CIBP @ 9950' and cap w/2 sx of cement.
Cut off and recover 7" casing from freepoint.
Use 9# gel mud and spot these cement plugs:
30 sx in and out of 7" stub
30 sx across top of Bone Springs @ 6843' if 7" stub below this depth.
30 sx in and out of 9-5/8" shoe @ 5002'.
10 sx in top of well.

13-3/8" and 9-5/8" casing strings will remain intact. Dry hole marker will be installed and location cleared and levelled.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>[Signature]</u>	TITLE <u>Dist. Drilling Supervisor</u>	DATE <u>4/22/71</u>
APPROVED BY <u>[Signature]</u>	TITLE <u>SUPERVISOR DISTRICT 1</u>	DATE <u>APR 26 1971</u>
CONDITIONS OF APPROVAL, IF ANY:		

RECEIVED

APR 23 1971

OIL CONSERVATION COMM.
HOBBS, N. M.