

State of New Mexico
Energy, Minerals and Natural Resources Department

Form C-103
Revised 1-1-89

DISTRICT I

1625 N. French Drive, Hobbs, NM 88240

OIL CONSERVATION DIVISION

310 Old Santa Fe Trail, Room 206
Santa Fe, New Mexico 87503

WELL API NO.	30-025-07337
5. Indicate Type of Lease	FED <input type="checkbox"/> STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No.	
7. Lease Name or Unit Agreement Name	NORTH HOBBS (G/SA) UNIT
Section	18
8. Well No.	141
9. Pool name or Wildcat	HOBBS (G/SA)

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101 FOR SUCH PROPOSALS.)	
1. Type of Well:	Oil Well <input type="checkbox"/> Gas Well <input type="checkbox"/> Other <input type="checkbox"/> Temporary Abandoned <input type="checkbox"/>
2. Name of Operator	OCCIDENTAL PERMIAN, LTD.
3. Address of Operator	1017 W STANOLIND RD.
4. Well Location	Unit Letter <u>M</u> <u>330</u> Feet From The <u>SOUTH</u> Line and <u>330</u> Feet From The <u>WEST</u> Line Section <u>18</u> Township <u>18-S</u> <u>38-E</u> NMPM LEA County
10. Elevation (Show whether DF, RKB, RT GR, etc.)	3673' GL

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
PLUG AND ABANDON <input checked="" type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG & ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>
OTHER: <input type="checkbox"/>	OTHER: <input type="checkbox"/>

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Well is TA'd with CIBP @3870' capped w/35'cmt. TOC @3835'.
CMT plug over bad csg @2869' to 3100'.

RUPU. Install BOP.
Move in and rack 2-7/8" workstring. 2900'.
Perforate thru 8-5/8" csg and the 10-3/4".
Spot cmt from 1950' to 2150'. Top of Anhy @2040'.
Tag cmt plug. @1950'.
Circ cmt behind 8-5/8" and 10-3/4" csg. Pump from surf thru sqz holes @270'. Bottom of surf csg @222'.
Leave csg full of cmt from 270' to surf.

THE COMMISSION MUST BE NOTIFIED 24 HOURS PRIOR TO THE BEGINNING OF PLUGGING OPERATIONS FOR THE C-103 TO BE APPROVED

Install dry hole marker 4' above ground level with well information. NHU 18-141, UL "M", Sec. 18, TWN 18-S, RNG 38-E.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Robert Gilbert TITLE COMPLETIONS SPECIALIST DATE 11/05/01
TYPE OR PRINT NAME ROBERT GILBERT TELEPHONE NO. 505/397-8206

(This space for State Use)

APPROVED BY _____ TITLE _____ DATE 11/05/01
CONDITIONS OF APPROVAL IF ANY: _____