

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

JUL 9 9 23 AM '65

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease
State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.
OG-4767

SUNDRY NOTICES AND REPORTS ON WELLS <small>(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)</small>	
1. <input checked="" type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER-	7. Unit Agreement Name
2. Name of Operator Marlo Drilling Company	8. Farm or Lease Name Mobil State
3. Address of Operator c/o Oil Reports & Gas Services, Box 763, Hobbs, New Mexico	9. Well No. 2
4. Location of Well UNIT LETTER J 1650 FEET FROM THE South LINE AND 2310 FEET FROM THE East LINE, SECTION 6 TOWNSHIP 18 S RANGE 34 E NMPM.	10. Field and Pool, or Wildcat E-K Queen
15. Elevation (Show whether DF, RT, GR, etc.) 4093 DF	12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/> TEMPORARILY ABANDON <input type="checkbox"/> PULL OR ALTER CASING <input type="checkbox"/> OTHER <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/> CHANGE PLANS <input type="checkbox"/> OTHER <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/> COMMENCE DRILLING OPNS. <input type="checkbox"/> CASING TEST AND CEMENT JOB <input type="checkbox"/> OTHER <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/> PLUG AND ABANDONMENT <input type="checkbox"/> OTHER <input type="checkbox"/>
---	---	---	---

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

It is proposed to plug and abandon as follows:

Spot 25 sack plug across perforations 4180-82.
Cut and pull 4 1/2" casing from approx. 3400'.
Spot 25 sack plug across stub at 3400'.
Spot 25 sack plug across top of salt at 1845'.
8 5/8" casing set at 326' to be left in hole with 25 sack plug across shoe.
10 sacks in top with regulation marker.
Mud between all plugs.
Clear and level location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED H. K. Smith	TITLE Agent	DATE July 8, 1965
APPROVED BY Joe X. [Signature]	TITLE [Signature]	DATE [Signature]
CONDITIONS OF APPROVAL, IF ANY:		