

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN TRIPLY
(Other instructions
verse side)CP
reForm approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

NM-01177-A

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐ DEPLETED	7. UNIT AGREEMENT NAME BUFFALO FEDERAL UNIT
2. NAME OF OPERATOR PAN AMERICAN PETROLEUM CORPORATION	8. FARM OR LEASE NAME
3. ADDRESS OF OPERATOR BOX 69, HOBBS, N. M. 88240	9. WELL NO. 6
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements. See also space 17 below.) At surface 660' FSL x 1980' FEL Sec. 33 (Unit 0, SW 1/4 SE 1/4)	10. FIELD AND POOL, OR WILDCAT CORBIN QUEEN, So.
14. PERMIT NO.	11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA 33-18-33 NMPM
15. ELEVATIONS (Show whether DF, RT, CR, etc.) 3742' R. D. B.	12. COUNTY OR PARISH LEA
	13. STATE NM

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐FRACTURE TREAT ☐SHOOT OR ACIDIZE ☐REPAIR WELL ☐(Other) ☐PULL OR ALTER CASING ☐MULTIPLE COMPLETE ☐ABANDON* ☒CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐FRACTURE TREATMENT ☐SHOOTING OR ACIDIZING ☐(Other) ☐REPAIRING WELL ☐ALTERING CASING ☐ABANDONMENT* ☐

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Well has been depleted and there no possibilities of a successful workover. Proposal to P+ A as follows:

1. Spot 25.04 cement plug 4477(PBD)-4073 to cover perfs 4434-53.
2. Cut + pull 4 1/2" from free point. (Set top of cement @ 3500')
3. Spot 25.04 in + out of 4 1/2" stub.
4. " 30 " , 3100 - 3000'
5. " 30 " , 1525 - 1425'
6. " 50 " , In + Out of 13 3/8" shoe @ 322'
7. " 10 " @ Surface + erect P+ A marker
8. Make final cleanup and restore ground to contour.

Procedure pursuant to telephone approval of 2-13-68,
Mr. G. R. Brown to D. C. Jones.

TD - 4500'

PBD - 4473'

4 1/2" CSA 4500' (Set top PWT - 3500')

13 3/8" CSA 322' (calculated)

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE

AREA SUPERINTENDENT

DATE **2-16-68**

(This space for Federal or State office use)

APPROVED BY

CONDITIONS OF APPROVAL, IF ANY:

TITLE

APPROVED

FEB 20 1968

A. R. BROWN

DISTRICT ENGINEER

DATE

*See Instructions on Reverse Side

0-4 USGS H
1- NSW
1- SUSP
1- RRY
1- (OROCO)
1- STATELAND