

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

SUNDY NOTICES AND REPORTS ON WELLS DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO REOPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE APPLICATION FOR PERMIT TO DRILL C-101 FOR SUCH PROPOSALS.		5a. Indicate Type of Lease State ☒ Fee ☐																
1. ☐ OIL WELL ☐ GAS WELL ☐ OTHER- Water Injection Well		5. State Oil & Gas Lease No. 062414																
2. Name of Operator Murphy H. Baxter		7. Unit Agreement Name N. EK Queen Unit																
3. Address of Operator P. O. Box 2040 Midland, Texas 79702		8. Farm or Lease Name Tract 7																
4. Location of Well UNIT LETTER F 1650 FEET FROM THE North LINE AND 2176 FEET FROM THE West LINE, SECTION 7 TOWNSHIP 18S RANGE 33E 34 N.M.P.M.		9. Well No. 2																
13. Elevation (Show whether DF, RT, GR, etc.) 4095 GR		10. Field and Pool, or Wildcat EK Yates 7 Rivers Queen																
12. County Lea																		
16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data <table border="0"> <tr> <td colspan="2">NOTICE OF INTENTION TO:</td> <td colspan="2">SUBSEQUENT REPORT OF:</td> </tr> <tr> <td>PERFORM REMEDIAL WORK ☐</td> <td>PLUG AND ABANDON ☒</td> <td>REMEDIAL WORK ☐</td> <td>ALTERING CASING ☐</td> </tr> <tr> <td>TEMPORARILY ABANDON ☐</td> <td>CHANGE PLANS ☐</td> <td>COMMENCE DRILLING OPHS. ☐</td> <td>PLUG AND ABANDONMENT ☐</td> </tr> <tr> <td>PULL OR ALTER CASING ☐</td> <td>OTHER ☐</td> <td>CASING TEST AND CEMENT JOB ☐</td> <td></td> </tr> </table>			NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:		PERFORM REMEDIAL WORK ☐	PLUG AND ABANDON ☒	REMEDIAL WORK ☐	ALTERING CASING ☐	TEMPORARILY ABANDON ☐	CHANGE PLANS ☐	COMMENCE DRILLING OPHS. ☐	PLUG AND ABANDONMENT ☐	PULL OR ALTER CASING ☐	OTHER ☐	CASING TEST AND CEMENT JOB ☐	
NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:																
PERFORM REMEDIAL WORK ☐	PLUG AND ABANDON ☒	REMEDIAL WORK ☐	ALTERING CASING ☐															
TEMPORARILY ABANDON ☐	CHANGE PLANS ☐	COMMENCE DRILLING OPHS. ☐	PLUG AND ABANDONMENT ☐															
PULL OR ALTER CASING ☐	OTHER ☐	CASING TEST AND CEMENT JOB ☐																
17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.																		

*Commission will be notified 24 hrs. prior to commencing work.

1. Trip in hole with CIBP. Set CIBP @ 4250'.
2. Spot 35' of cement on top of CIBP
3. Displace hole with mud-laden fluid. Close pipe rams. Test plug and casing to 500#'s.
4. Perforate 4 holes @ 1700'. (Top of anhydrite @ 1730'.) Circulate or squeeze 50 sks. or sufficient cement to isolate anhydrite section. WOC.
5. Tag and test plug to 500#'s.
6. Spot 50 sks. of cement above and below surface casing shoe @ 394'. WOC.
7. Tag plug. Cut off bradenhead and weld steel plate on casing. Set P & A marker.

I, hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Chuck Sledge TITLE Petroleum Engineer DATE 8-13-87

ORIGINAL SIGNED BY JERRY SEXTON
APPROVED BY DISTRICT 1 SUPERVISOR TITLE _____ DATE AUG 25 1987
CONDITIONS OF APPROVAL, IF ANY:

1. 1990年12月25日，在俄罗斯莫斯科市，俄罗斯总统叶利钦在克里姆林宫正式签署《俄罗斯联邦宪法》，宣布俄罗斯联邦为总统制国家。