

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease State ☒ Fee ☐
5. State Oil & Gas Lease No. 06-1633
7. Unit Agreement Name
8. Farm or Lease Name East EK Unit
9. Well No. 9
10. Field and Pool, or Wildcat EK Queen West
12. County Lea

SUNDY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL ☐ GAS WELL ☐ OTHER: Injection shut-in
2. Name of Operator Conoco Inc
3. Address of Operator P.O. Box 460, Hobbs, NM 88240
4. Location of Well UNIT LETTER E, 1650 FEET FROM THE North LINE AND 330 FEET FROM THE West LINE, SECTION 23 TOWNSHIP 18S RANGE 24E NMPM.
15. Elevation (Show whether DF, RT, GR, etc.)

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK ☐	PLUG AND ABANDON ☒	REMEDIAL WORK ☐	ALTERING CASING ☐
TEMPORARILY ABANDON ☐	CHANGE PLANS ☐	COMMENCE DRILLING OPERATIONS ☐	PLUG AND ABANDONMENT ☐
PULL OR ALTER CASING ☐	OTHER ☐	CASING TEST AND CEMENT JOBS ☐	OTHER ☐

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1705.

1. m.R.D. dump 3sx ± of cement on top of retainer at 4639' wait ½ hr. ±, spot mud from 4334' - 2105' (354 bbls ±), spot a cement plug from 2105' - 2005' (1sx ±), spot mud from 2005' - 455', 4 TSPF, perforate the 4-½" production casing at 455', if circulation can be broken, isolate the 3-¾" casing shoe, circulate annulus with 100 sx cement and displace cement to 355' in 4-½" casing, huc for ½ - 1 hr., if TOC is below 355' fill 4-½" casing to 355' with cement, if circulation cannot be broken, spot a cement plug from 455' - 355' (7sx ±), huc ½ - 1 hr. If TOC is below 355', fill 4-½" casing to 355' with cement as required. Spot mud from 355' - 100'
2. Spot a cement plug from 100' - 0' (7sx ±), cut casing shoe to restored ground level, fill the casing from the cement plug to the surface with cement, sand, or gravel.
3. Erect a permanent steel P+A marker over small bore, clean location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Concilio TITLE Administrative Supervisor DATE 8-11-86

ORIGINAL SIGNED BY JERRY SEXTON
DISTRICT 1 SUPERVISOR

APPROVED BY _____ TITLE _____

DATE AUG 14 1986

CONDITIONS OF APPROVAL, IF ANY:

NMOCO-Hobbs
File