

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

OIL CONSERVATION DIVISION

P. O. BOX 2088

SANTA FE, NEW MEXICO 87501

0+6-NMOCD-_____ 1-File _____ LM

2-Midland JA LR 1-Engr. _____

1-Foreman- EF _____

Form C-103
Revised 10-1-7

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.O.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease
State ☐ Fee ☒

5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER _____	7. Unit Agreement Name
2. Name of Operator Getty Oil Company	8. Farm or Lease Name H.D. McKinley
3. Address of Operator P.O. Box 730, Hobbs, New Mexico 88240	9. Well No. 8
4. Location of Well UNIT LETTER H 2310 FEET FROM THE N LINE AND 430 FEET FROM THE E LINE, SECTION 30 TOWNSHIP 18-S RANGE 38-E NMPM.	10. Field and Pool, or Wildcat Hobbs Blinebry
15. Elevation (Show whether DF, RT, GR, etc.) 3648' DF	12. County Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input checked="" type="checkbox"/> Drill out cement, add perfs, treat	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1503.

1. Pull rods and tubing
2. Clean out with bit to PBTD 5990'.
3. Drill out float collar and cement to 6025'.
4. Perforate Blinebry at 5830', 31', 32', 5908', 09', 14', 16', 6000', 03', 11', 12', 13', and 14' (13 holes)
5. Set pkr. at 5660'.
6. Acidize Blinebry perfs 5757'-6014' with 5500 gal. 15% HCl.
7. Swab load.
8. Pull pkr.
9. Run tbgr., rods, and pump and return to production.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Dale R. Crockett TITLE Area Superintendent DATE 3/8/84

ORIGINAL SIGNED BY JERRY SEXTON
DISTRICT I SUPERVISOR

APPROVED BY _____ TITLE _____

CONDITIONS OF APPROVAL, IF ANY:

MAR 15 1984

RECEIVED
MAR 13 1964
O.C.D.
HONAS OFFICE