

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

RECEIVED

FORM APPROVED
Budget Bureau No. 1004-0135
Expires: September 30, 1990

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.

SUBMIT IN TRIPLICATE

1. Type of Well

☒ Oil Well ☐ Gas Well ☐ Other

2. Name of Operator

Kaiser-Francis Oil Company

3. Address and Telephone No.

P. O. Box 21468, Tulsa, OK 74121-1468 918-494-0000

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

Unit B
660' FNL & 1980' FEL of Sec. 31-18S-34E

5. Lease Designation and Serial No.

NM-0245247

6. If Indian, Allottee or Tribe Name

-

7. If Unit or C.A. Agreement Designation

-

8. Well Name and No.

McElvain-Federal #2

9. API Well No.

30-025-25188

10. Field and Pool, or Exploratory Area

EK (Bone Springs)

11. County or Parish, State

Lea, NM

12. CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☒ Notice of Intent
☐ Subsequent Report
☐ Final Abandonment Notice

TYPE OF ACTION

- ☒ Abandonment
☐ Recompletion
☐ Plugging Back
☐ Casing Repair
☐ Altering Casing
☐ Other
☐ Change of Plans
☐ New Construction
☐ Non-Routine Fracturing
☐ Water Shut-Off
☐ Conversion to Injection

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

The following is our proposal to P & A the above well:

1. Set CIBP @ 8750' w/35' cmt on top.
2. TIH w/tbg. Load hole w/10# brine w/25# gel/bbl.
3. Shoot & pull 4½" casing (est. @ 3000').
4. Spot 40 sx cmt plug 50' in & 50' out of 4½" casing. Tag.
5. Shoot & pull 8 5/8" casing (est. @ 2000').
6. Spot 100 sx cmt plug 50' in & 50' out of 8 5/8" casing. Tag.
7. Spot 100 sx cmt plug from 400'-300'.
8. Spot 50 sx cmt plug @ surface.
9. Weld on cap and install DH marker.

Plugging operations to commence approximately 9/15/90.

* NOTIFY BLM @ (505) 393-3612 PRIOR TO COMMENCING PLUGGING OPERATIONS.

14. I hereby certify that the foregoing is true and correct

Signed

Title

Charlotte Van Valkenburg
Technical Coordinator

Date 8/15/90

(This space for Federal or State office use)

Approved by

Title

Date

Conditions of approval, if any:

8.31.90