

STATE OF NEW MEXICO  
ENERGY AND MINERALS DEPARTMENT

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

OIL CONSERVATION DIVISION  
P. O. BOX 2088  
SANTA FE, NEW MEXICO 87501

Form C-103  
Revised 10-1-78

5a. Indicate Type of Lease  
State ☒ Fee ☐  
5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator Chevron U.S.A. Inc.	8. Farm or Lease Name Lea ACF State
3. Address of Operator P.O. Box 670, Hobbs, NM 88240	9. Well No. 1
4. Location of Well UNIT LETTER A 660 FEET FROM THE North LINE AND 660 FEET FROM East THE LINE, SECTION 35 TOWNSHIP 18S RANGE 36E NMPM.	10. Field and Pool, or Wildcat Wildcat Devonian <i>Lea ACF</i>
11. Elevation (Show whether DF, RT, GR, etc.) 3766' GR	12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

It is proposed to P&A as follows:

- Plug #1 Set CIBP at 6235 and cap w/ 35' cmt. (Perfs 6285-6320)
- Plug #2 Spot 100' cmt plug in 5 1/2" csg, 4400- 4500' (Int at 4500')
- Plug #3 Spot 100' cmt plug in 5 1/2" csg, 2700- 2800' (Base of Salt at 2800')
- Pull 5 1/2" casing f/ 1800'. (TOC at 2000')
- Plug #4 Spot 100' cmt plug across 5 1/2" stub at 1800'.
- Plug #5 Set 50' surface plug in 9 5/8" casing.

Install dry hole marker.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

CRED M. E. Akers TITLE Staff Drilling Engineer DATE July 10, 1987

ORIGINAL SIGNED BY JERRY SEXTON  
APPROVED BY DISTRICT 1 SUPERVISOR TITLE \_\_\_\_\_ DATE \_\_\_\_\_

CONDITIONS OF APPROVAL, IF ANY: