

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	State ☒ Fee ☐
5. State Oil & Gas Lease No.	E-2519

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL ☒ GAS WELL ☐ OTHER: <u>temp. abandoned</u>	7. Unit Agreement Name
2. Name of Operator CONOCO INC.	8. Farm or Lease Name EK Deep
3. Address of Operator P. O. Box 460, Hobbs, N.M. 88240	9. Well No. 1
4. Location of Well UNIT LETTER <u>M</u> <u>715</u> FEET FROM THE <u>South</u> LINE AND <u>990</u> FEET FROM THE <u>West</u> LINE, SECTION <u>22</u> TOWNSHIP <u>18S</u> RANGE <u>34E</u> N.M.P.M.	10. Field and Pool, or Wildcat <u>Undesignated Bone Spring</u> <u>Undesignated Wolfcamp</u> <u>Undesignated Morrow</u>
15. Elevation (Show whether DF, RT, GR, etc.)	12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK ☐	PLUG AND ABANDON ☒	REMEDIAL WORK ☐	ALTERING CASING ☐
TEMPORARILY ABANDON ☐	CHANGE PLANS ☐	COMMENCE DRILLING OPNS. ☐	PLUG AND ABANDONMENT ☐
PULL OR ALTER CASING ☐	OTHER ☐	CASING TEST AND CEMENT JOB ☐	OTHER ☐

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1703.

- ① The subject well was TA'd on 5-18-86.
- ② MIRU, R1H w/ open ended tbg to 9900' & circ. wellbore w/ mud. Spot 100' cmt plug from 7703'-7603' to isolate Bone Spring. Spot 100' cmt plug from 4452'-4352' to isolate 9 5/8" shoe.
- ③ Spot 5 bbls 10% acetic acid from 1500'-1369' & perf @ 1500' w/ 4 JSPE. Establish circ. & pump 250 sxs to circ. to surface. If circ. is not broken, sqz 50-75 sxs cmt into perts and displace cmt to 1450'. If a pump-in rate is not obtained, spot a 50' cmt plug from 1500'-1450'.
- ④ Spot a 100' cmt plug from 100'-surface. Cut off csg 3' below restored ground level and install P & A marker. Clear location and rig down.
- ⑤ A P & A sketch is attached.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED [Signature] TITLE Administrative Supervisor DATE 9-18-86

ORIGINAL SIGNED BY KERRY TEXTON

APPROVED BY DIRECTOR TITLE DIRECTOR DATE SEP 22 1986