

OIL CONSERVATION DIVISION

P. O. BOX 2088

SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
B1040	

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)	
1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER-	7. Unit Agreement Name
2. Name of Operator Amerada Hess Corporation	8. Farm or Lease Name State V "A"
3. Address of Operator Drawer "D", Monument, New Mexico 88265	9. Well No. 2
4. Location of Well UNIT LAYERS L 1980 FEET FROM THE South LINE AND 660 FEET FROM THE West LINE, SECTION 23 TOWNSHIP 17S RANGE 34E NMPM.	10. Field and Pool, or Whdeat Vacuum G/SA
15. Elevation (Show whether DF, RT, GR, etc.) 4028' DF	12. County Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>
OTHER <input type="checkbox"/>	OTHER <input type="checkbox"/>
PLUG AND ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Plan to pull rods, pump and 2-7/8" tubing. Set bridge plug in 5½" casing and spot 100' of cement on top of bridge plug. Test w/1000# pressure. Run packer and tubing and test tubing w/2500#. Perforate 5½" casing at 1675' w/two jet shots. Set cement retainer in 5½" casing at 1450' and squeeze thru perfs. at 1675'w/125 sacks and attempt to circulate cement to surface. WOC and drill out retainer and cement and test w/1000#. Drill out cement and bridge plug, clean out open hole to 4671'. Re-run tubing, pump and rods and resume production.

THE COMMISSION MUST BE NOTIFIED
24 HOURS PRIOR TO COMMENCING WORK

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.		
SIGNED <u>E. A. Fisher</u>	TITLE <u>Supv. Adm. Ser.</u>	DATE <u>6/11/80</u>
APPROVED BY <u>[Signature]</u>	TITLE <u>[Signature]</u>	DATE <u>JUN 16 1981</u>
CONDITIONS OF APPROVAL, IF ANY:		