

NEW MEXICO OIL CONSERVATION COMMISSION

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. B-1482

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT --" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- 2. Name of Operator CITIES SERVICE OIL COMPANY 3. Address of Operator P.O. Box 69, Hobbs, N.M. 38240 4. Location of Well UNIT LETTER K 2310 FEET FROM THE South LINE AND 1650 FEET FROM THE West LINE, SECTION 35 TOWNSHIP 17S RANGE 35E N.M.P.M. 15. Elevation (Show whether DF, RT, GR, etc.) 3917 OF	7. Unit Agreement Name 8. Farm or Lease Name State BJ 9. Well No. 2 10. Field and Pool, or Wildcat Vacuum Abo Reef 12. County Lea
--	---

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

We propose to plug and abandon the above well in the following manner:

1. Pull rods and tubing
2. Load hole with mud laden fluid
3. Spot a 50 sack cement plug across perfs 8940-9000.
4. Cut and pull approx. 4000' of 5½" casing.
5. Spot a 35 sack cement plug @ approx. 3900-4100, ½ in and ½ out of 5½" casing stub at 4000'.
6. Spot a 35 sack cement plug at approx. 3400-3600, ½ in and ½ out of 8 5/8" casing shoe @ 3501'.
7. Set a 10 sack cement surface ^{plug} @ approx. 30-0' with a 4" dry hole marker extending 4' above ground.
8. Clean location of all equipment and debris.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED _____ TITLE **Dist. Admin. Supervisor** DATE **Oct. 15, 1971**

Orig. Signed by
Joe D. Ramey
Dist. I, Supv.

APPROVED BY _____ TITLE _____ DATE **OCT 18 1971**

CONDITIONS OF APPROVAL, IF ANY:

RECEIVED

OCT 1 1971

OIL CONSERVATION COMM.
HOUSTON, TEX.