

OIL CONSERVATION DIVISION

P. O. BOX 2088

SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-77

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease
State ☒ For ☐
5. State Oil & Gas Lease No.
B-1287-1

SUNDARY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT TO DRILL" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐	7. Unit Agreement Name
2. Name of Operator Texaco Producing Inc.	8. Farm or Lease Name West Lovington Unit
3. Address of Operator PO Box 728, Hobbs, New Mexico 88240	9. Well No. 4C
4. Location of Well UNIT LETTER C, 1980 FEET FROM THE West LINE AND 660 FEET FROM THE North LINE, SECTION 7 TOWNSHIP 17S RANGE 36E NMPM.	10. Field and Pool, or Wildcat West Lovington San Andres,
15. Elevation (Show whether DF, RT, GR, etc.) 3921' GL	12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK ☒	PLUG AND ABANDON ☐	REMEDIAL WORK ☐	ALTERING CASING ☐
TEMPORARILY ABANDON ☐	CHANGE PLANS ☐	COMMENCE DRILLING OPNS. ☐	PLUG AND ABANDONMENT ☐
PULL OR ALTER CASING ☐	OTHER ☐	CASING TEST AND CEMENT JOBS ☐	OTHER ☐

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- 1) MIRU. Pull rods and pump. Install BOP. Pull tubing.
- 2) GIH with 4 3/4" bit. Clean out to TD at 5160'.
- 3) Run GR-CNL-CCL 5160'-4160'. Pick Grayburg perms.
- 4) GIH with packer to $\pm$ 4600'.
- 5) Spot 15 gallons Unichem 425 surfactant in 15 barrels fresh water and 165 gallons 405 scale converter in 7 barrels fresh water across open hole. SION.
- 6) Acidize San Andres OH 4712'-5160' with 6000 gallons 15% NEFE in 2 stages with 1000# rocksalt between stages as a block (3 BPM, 4000#).
- 7) Flow back load. Pull packer. Set RBP at $\pm$ 4700'.
- 8) Perforate Grayburg with 4" casing gun with 2 jsps.
- 9) GIH with packer. Set at $\pm$ 4500'.
- 10) Acidize Grayburg perms with 4000 gallons 15% NEFE and 50% excess ball sealers. (3 BPM, 4000#).
- 11) Flow back load. Pull packer.
- 12) Run production equipment and obtain a good Grayburg test.
- 13) After several days or weeks, pull RBP and obtain a commingled test.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

397-3571

SIGNED Ja Head TITLE Hobbs Area Superintendent DATE 2/8/88

APPROVED BY Paul Gantz TITLE Geologist DATE 2/8/88

CONDITIONS OF APPROVAL, IF ANY:

Intent Cancelled - see C-103 dated 11-11-88