

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

OIL CONSERVATION DIVISION

P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
B-1501	

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>		7. Unit Agreement Name
2. Name of Operator		8. Farm or Lease Name
TEXACO Inc.		Central Vacuum Unit
3. Address of Operator		9. Well No.
P. O. Box 728, Hobbs, New Mexico 88240		33
4. Location of Well		10. Field and Pool, or Wildcat
UNIT LETTER <u>0</u> , <u>660</u> FEET FROM THE <u>South</u> LINE AND <u>1980</u> FEET FROM		Vacuum Grayburg
THE <u>East</u> LINE, SECTION <u>30</u> TOWNSHIP <u>17-S</u> RANGE <u>35-E</u> N.M.P.M.		San Andres
15. Elevation (Show whether DF, RT, GR, etc.)		12. County
3989' (DF)		Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data			
NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input checked="" type="checkbox"/> Deepen in same zone & treat	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Rig up. Pull rods & pump. Install Bop. Pull Tubing.
2. Clean out. Deepen Well to approx. 4705'.
3. Spot 500 gals. of 50/50 mix of Xylene & 15% NEFE Acid over open-hole. Reverse out.
4. Spot 15 Bbls. Ammonium Bicarbonate solution across open-hole. Squeeze addl. 15Bbls. of same solution in open-hole.
5. Set pkr. @ 3740'. Acidize open-hole 4104'-4705' w/7000 gals. 15% NEFE Acid in 4-stages using rock salt & moth balls between stages. Flush w/75 Bbls. Gelled Brine.
6. Install pumping equipment. Test & place on production.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Eddie W. Seay TITLE Asst. Dist. Mgr. DATE 1-21-83

APPROVED BY EDDIE W. SEAY TITLE Asst. Dist. Mgr. DATE JAN 25 1983
CONDITIONS OF APPROVAL, IF ANY:

RECEIVED

JAN 24 1983

HOSEA OFFICE