

NO. COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fed <input type="checkbox"/>
5. State Oil & Gas Lease No.	
B-1482	

## SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input checked="" type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER		7. Unit Agreement Name
2. Name of Operator CITIES SERVICE COMPANY		8. Farm or Lease Name STATE K
3. Address of Operator P. O. Box 1919, Midland, Texas 79702		9. Well No. 5
4. Location of Well UNIT LETTER H, 2310 FEET FROM THE Norht LINE AND 330 FEET FROM THE East LINE, SECTION 27, TOWNSHIP 17S, RANGE 35E NMPM.		10. Field and Pool, or Wildcat Vacuum Glorieta
15. Elevation (Show whether DF, RT, GR, etc.) 3922' GR		12. County LEA

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK ☐  
TEMPORARILY ABANDON ☐  
PULL OR ALTER CASING ☐  
OTHER ☐

PLUG AND ABANDON ☒  
CHANGE PLANS ☐  
OTHER ☐

REMEDIAL WORK ☐  
COMMENCE DRILLING OPNS. ☐  
CASING TEST AND CEMENT JOB ☐  
OTHER ☐

ALTERING CASING ☐  
PLUG AND ABANDONMENT ☐

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

T.D. 9000', PBTD 6170'. It is proposed to plug and abandon this well as follows:

1. MIRU pulling unit, pull rods, pump and tubing.
2. Set a CIBP @ approx. 6000' and dump 3 sacks (25') of cement on top of BP. RD pulling unit.
3. RU casing pullers, shoot off casing @ approx. 3200', pull and lay down casing.
4. RIH with 2-3/8" OD tubing and spot a 100' cement plug @ approx. 3250-3150', 1/2 in the 5 1/2" casing stub and 1/2 in the 8-5/8" casing. POOH with tubing to 100'.
5. Spot a 30 sack cement surface plug @ approx. 100'-surface and install a 4" dry hole marker to designate a plugged and abandoned location.

100' PLUG AT TOP OF GRAYBURG  
100' PLUG AT 1300'

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Elmer Startz

TITLE Reg. Oper. Mgr.-Prod.

DATE 1-5-82

APPROVED BY Jerry Lipton  
CONDITIONS OF APPROVAL, IF ANY:

TITLE SUPERVISOR

DATE JAN 1982