

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease
State ☒ Fee ☐

5. State Oil & Gas Lease No.

B-155

SUNDARY NOTICES AND REPORTS ON WELLS

DO NOT USE THIS FORM FOR THE STATE OF NEW MEXICO OR FOR A DIFFERENT RESERVOIR.
USE IN PLACE OF THE STATE OF NEW MEXICO OR FOR A DIFFERENT RESERVOIR.

1. ☒ OIL WELL ☐ GAS WELL ☐ OTHER	7. Unit Agreement Name
2. Name of Operator Texaco Inc.	8. Form of Lease Name New Mexico 'O' St. NCT-1
3. Address of Operator P. O. Box 728, Hobbs, New Mexico 88240	9. Well No. 19
4. Location of Well UNIT LETTER F 1980 FEET FROM THE North LINE AND 2179 FEET FROM THE West LINE, SECTION 36 TOWNSHIP 17-S RANGE 34-E N.M.P.M.	10. Field and Pool, or Wildcat Vacuum Glorieta
15. Elevation (Show whether DF, KT, GR, etc.) 4002' (GL)	12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐
TEMPORARILY ABANDON ☐
PULL OR ALTER CASING ☐

PLUG AND ABANDON ☐
CHANGE PLANS ☐

OTHER Open Addl. Pay in Glorieta & return well to production ☒

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐
COMMENCE DRILLING OPER. ☐
CASING TEST AND CEMENT JOB ☐

ALTERING CASING ☐
PLUG AND ABANDONMENT ☐

OTHER 1 ☐

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Rig up. Install BOP.
2. Mill over & pull pump seat stuck in Glorieta string @ 5850'.
3. Clean out to 6200'.
4. Perforate 2 7/8" OD Glorieta Casing W/1-JSPF @ 6008', 6011', 6013', 6016', 6018', from 6130' - 6135', and 6142' - 6146'.
5. Set RBP @ 6100' and spot acid on perforations 6130' - 6146'. Set packer @ 6100'.
6. Acidize perforations 6130' - 6146' W/2000 gal. 15% LSTNE Acid in 2-equal stages using 300# rock salt between stages. Flush W/treated fresh water.
7. Reset RBP @ 6050'. Spot acid over old & new perforations 5980' - 6018'. Set packer @ 5950'.
8. Acidize perforations 5980' - 6018' W/2000 gal. 15% LSTNE Acid in 2-equal stages, using 300# rock salt between stages. (Continued on page 2)

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED [Signature] TITLE Asst. Dist. Supt. DATE 8-19-76
APPROVED BY _____ TITLE _____ DATE _____
CONDITIONS OF APPROVAL, IF ANY: