

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO RE-OPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE APPLICATION FOR PERMIT - (FORM C-101) FOR SUCH PROPOSALS.)

1. ☒ OIL WELL ☐ GAS WELL ☐ OTHER-

2. Name of Operator
TEXACO Inc.

3. Address of Operator
P.O. Box 728, Hobbs, New Mexico 88240

4. Location of Well
UNIT LETTER J 1800 FEET FROM THE South LINE AND 1800 FEET FROM
THE East LINE, SECTION 36 TOWNSHIP 17-S RANGE 34-E N.M.P.M.

15. Elevation (Show whether DF, RT, GR, etc.)
3991' (GR)

5a. Indicate Type of Lease
State ☒ Fee ☐

5. State Oil & Gas Lease No.
B-155

7. Unit Agreement Name
-

8. Farm or Lease Name
New Mexico "0" St. NCT-1

9. Well No.
12

10. Field and Pool, or Valdecut
Vacuum Glorieta

12. County
Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	
		OTHER <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Rig up.
2. Run CIBP down 2-7/8" Blinbry & Glorieta strings. Set @ 5300' in Blinbry string & 5900' in Glorieta. Dump 35' cement on each BP.
3. Run free point indicator, cut both strings of 2-7/8" casing, load hole with mud.
4. Pull one string and use other string to spot 100' (40 sx) cement plug across interval where casing was cut.
5. Pull casing to surface, spot 100' (40 sx) cement plug across surface casing shoe 630-530'.
6. Spot 30' (10 sx) cement plug @ surface.
7. Install markers and clean location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED [Signature] TITLE Asst. Dist. Supt. DATE 2-22-77

APPROVED BY Jerry Sexton TITLE Dist. I, Supv. DATE FEB 24 1977

CONDITIONS OF APPROVAL, IF ANY: