

1. NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
J.S.G.S.		
LAND OFFICE		
OPERATOR		

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

<b>SUNDRY NOTICES AND REPORTS ON WELLS</b> <small>(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)</small>		5a. Indicate Type of Lease State <input type="checkbox"/> Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.		
6. <input checked="" type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER-		7. Unit Agreement Name
Name of Operator Read & Stevens, Inc.		8. Firm or Lease Name Hooper "A"
Address of Operator P. O. Box 1518, Roswell, N. M. 88201		9. Well No. 1
Location of Well UNIT LETTER <u>I</u> <u>2121.4</u> FEET FROM THE <u>South</u> LINE AND <u>801.4</u> FEET FROM <u>East</u> THE <u>7</u> LINE, SECTION <u>19-S</u> TOWNSHIP <u>35-E</u> RANGE <u>35-E</u> NMPM.		10. Field and Pool, or Wildcat Scharb Bone Spring
11. Elevation (Show whether DF, RT, GR, etc.) 3853.8' GR - 3865' RKB		12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/> TEMPORARILY ABANDON <input type="checkbox"/> PULL OR ALTER CASING <input type="checkbox"/> OTHER <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/> CHANGE PLANS <input type="checkbox"/> OTHER <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/> COMMENCE DRILLING OPNS. <input type="checkbox"/> CASING TEST AND CEMENT JOBS <input type="checkbox"/> OTHER <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/> PLUG AND ABANDONMENT <input type="checkbox"/> OTHER <input type="checkbox"/>
---	---	--	---

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

TD 10148'. 2 3/8" tubing fished and recovered to 5350'. 4 1/2" casing cut and-pulled at 5343'. Propose to plug and abandon as follows:

1. Set 35 sx. cement plug across 4 1/2" casing stub from 5300' to 5400'.
2. Set 35 sx. cement plug at top of Queen from 4580' to 4680'.
3. Set 35 sx. cement plug across 8-5/8" casing shoe from 3925' to 4025'.
4. Cut and pull 8 5/8" casing.
5. Set 50 sx. cement plug 50' above and 50' below 8 5/8" casing stub.
6. Set 50 sx. cement plug across 12 3/4" casing shoe from 330' to 440'.
7. Set 15 sx. surface plug and install dry hole marker.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Shawn Hamilton TITLE Agent DATE 11-13-78

APPROVED BY Orig. Signed by Jerry Sexton TITLE Dist. 1. Supv. DATE NOV 17 1978

CONDITIONS OF APPROVAL Expires 5/18/79