

Submit 3 Copies
to Appropriate
District Office

State of New Mexico
Energy, Minerals and Natural Resources Department

Form C-103
Revised 1-1-89

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION
P.O. Box 2088
Santa Fe, New Mexico 87504-2088

WELL API NO.

5. Indicate Type of Lease

STATE ☐

FEE ☒

6. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"
(FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:

OIL
WELL ☒

GAS
WELL ☐

OTHER

2. Name of Operator

Mobil Producing TX & NM Inc.

3. Address of Operator c/o Mobil Exploration & Producing TX & NM, US Inc.

P.O. Box 633, Midland, TX 79702

8. Well No.

/

9. Pool name or Wildcat

Scharb Bone Springs

4. Well Location

Unit Letter 0 : 801' Feet From The South Line and 1839' Feet From The East Line

Section 17

Township 19N

Range 35E

NMPM

Lea

County

10. Elevation (Show whether DF, RKB, RT, GR, etc.)

Zero is KB 18' AGL GL:3826'

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐

PLUG AND ABANDON ☒

TEMPORARILY ABANDON ☐

CHANGE PLANS ☐

PULL OR ALTER CASING ☐

OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐

ALTERING CASING ☐

COMMENCE DRILLING OPNS. ☐

PLUG AND ABANDONMENT ☐

CASING TEST AND CEMENT JOB ☐

OTHER: ☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. MIRU Wb Unit. Unseat pump, POOH w/rods & pump. NU BOP, test Release TAC, POOH w/tbg.
2. Set CIBPC ±8250' + 50' (5sk) cmt cap.
3. Cut 5½" K-55 csg @ ± 7500', POOH w/csg.
4. RIH w/tbg, circ well w/ 10 ppg gelled brine. Spot 150' cmt plug (31 sk) from 7425-7575'.
5. Set 150' (41 sk) across 8 3/8" shoe, 4025 - 4175'.
6. Set 150' (41 sk) plug across 13 3/8" shoe inside 8 5/8, 345 - 495'.
7. Set 100' (27 sk) surface plug.
8. Cut csg 3' below ground, weld on plate and P & A marker. Clean location.
Procedure discussed w/Jerry Sexton (Director - NMOCD) on 9-15-89.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE

Shirley Todd

TITLE

MOBIL EXPLORATION & PROD. CO.
AS AGENT FOR MOBILE OIL CO.

DATE 10-12-89

TYPE OR PRINT NAME

Shirley Todd

915 688-2585
TELEPHONE NO.

(This space for State Use)

ORIGINAL SIGNED BY JERRY SEXTON
DISTRICT I SUPERVISOR

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

ALL OPERATIONS MUST BE NOTIFIED 24
HOURS PRIOR TO THE BEGINNING OF
PLUGGING OPERATIONS FOR THE C-103
TO BE APPROVED.

OCT 16 1989