

OIL CONSERVATION DIVISION

P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease
State ☐ Fee ☒
5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

OIL WELL ☒ GAS WELL ☐ OTHER ☐	7. Unit Agreement Name
Name of Operator Harvey E. Yates Company	8. Farm or Lease Name Howry "25"
Address of Operator P.O. Box 1933, Roswell, New Mexico 88201	9. Well No. 1
Location of Well UNIT LETTER <u>E</u> , <u>1650</u> FEET FROM THE <u>North</u> LINE AND <u>330</u> FEET FROM THE <u>West</u> LINE, SECTION <u>25</u> TOWNSHIP <u>17S</u> RANGE <u>37E</u> NMPM.	10. Field and Pool, or Wildcat Hobbs Channel Bone Springs <i>Hobbs Channel well</i>
11. Elevation (Show whether DF, RT, GR, etc.) 3705.8 GL	12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐	PLUG AND ABANDON ☒	REMEDIAL WORK ☐	ALTERING CASING ☐
TEMPORARILY ABANDON ☐	CHANGE PLANS ☐	COMMENCE DRILLING OPNS. ☐	PLUG AND ABANDONMENT ☐
PULL OR ALTER CASING ☐	OTHER ☐	CASING TEST AND CEMENT JOBS ☐	OTHER ☐

7. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1503.

Casing Size	Wt & GRD	Depth	SXS Cmt.	TOC	Existing perfs:
13 3/8"	54.5#	457'	475	Surface	8486-8515' BS
8 5/8"	24 & 32#	4602'	1700	Surface	9404-9408' BS
5 1/2"	17#	11,565'	1535	4844' (CBL)	9440-9450' BS
					10,054-70 & 10,080
					thru 94' Wolfcamp

Recommended Procedure:

NOTE: Baker Loc set, SN and one jt tbg left in hole. Packer at 10,004'

- Pump plugs as follows:
Set CIBP @ 9950' with 30' cmt on top.
100' plug from 9450' to 9350' (across BS perfs)
100' plug from 8515' to 8415' (across BS perfs) and Tag
100' plug from 5622' to 5522' (across top of San Andres)
- Run free point for 5 1/2" csg.
- Cut and pull approx. 4500' plus or minus of 5 1/2" csg.
- Pump plugs as follows:
100' plug @ 5 1/2" cut off (50' in and out) and tag
100' plug from 2200' to 2100' (across top of Anhy)
50' plug @ surface
- Install dry hole marker

8. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Jerry Sexton TITLE Production Manager DATE April 2, 1987

ORIGINAL SIGNED BY JERRY SEXTON
DISTRICT I SUPERVISOR

APPROVED BY _____ TITLE _____ DATE APR 7 1987

CONDITIONS OF APPROVAL, IF ANY:

100-100000

REC-100
APR 3 1987
OCD
HOBBS OFFICE