

Submit 3 Copies
to Appropriate
District Office

State of New Mexico
Energy, Minerals and Natural Resources Department

Form C-103
Revised 1-1-89

DISTRICT I
P.O. Box 1980, Hobbs NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION

P.O. Box 2088
Santa Fe, New Mexico 87504-2088

| | |
|--------------------------------------|--|
| WELL API NO. | 30-025-30704 |
| 5. Indicate Type of Lease | STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/> |
| 6. State Oil & Gas Lease No. | |
| 7. Lease Name or Unit Agreement Name | Sharp Shooter 2 State |
| 8. Well No. | 2 |
| 9. Pool name or Wildcat | Young Bone Spring, North |

| | |
|--|--|
| SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.) | |
| 1. Type of Well: OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER | |
| 2. Name of Operator Santa Fe Energy Resources, Inc. | |
| 3. Address of Operator 550 W. Texas, Suite 1330, Midland, TX 79701 | |
| 4. Well Location Unit Letter <u>H</u> : <u>2310</u> Feet From The <u>North</u> Line and <u>330</u> Feet From The <u>East</u> Line Section <u>2</u> Township <u>18S</u> Range <u>32E</u> NMPM <u>Lea</u> County | |
| 10. Elevation (Show whether DF, RKB, RT, GR, etc.) 3899' GR | |

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐
PULL OR ALTER CASING ☐
OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐
COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐
CASING TEST AND CEMENT JOB ☐
OTHER: ☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

It is planned to plug & abandon the subject well as follows:

1. Circulate hole w/ drilling mud.
2. Set a CIBP at 3100' with 35' of cement on top of plug.
3. Cut off 5-1/2" casing at 2700' (TOC @ 2755' by CET). Pull casing.
4. Spot 45 sx Cl "C" cmt across 5-1/2" csg stub and across 8-5/8" csg shoe @ 2745' (spot plug from 2800' to 2600').
5. Circ hole w/ drlg mud and set 60 Cl "C" cmt plug from 516' to 316' (13-3/8" csg shoe @ 416').
6. Set 25 sx surface plug. Cut-off wellhead, weld on plate and put up marker.

This work is expected to begin on June 15, 1997.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Terry McCullough TITLE Sr. Production Clerk DATE 3/18/97
TYPE OR PRINT NAME Terry McCullough TELEPHONE NO. 915/687-3551

(This space for State Use) ORIGINAL SIGNED BY
GARY WINK
FIELD REP. II

APPROVED BY _____ TITLE _____ DATE _____
CONDITIONS OF APPROVAL, IF ANY:

MAR 20 1997