

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION

P.O. Box 2088
Santa Fe, New Mexico 87504-2088

WELL API NO.	30-025-04171
5. Indicate Type of Lease	STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No.	
7. Lease Name or Unit Agreement Name	Union Texas State "A"
8. Well No.	1
9. Pool name or Wildcat	Eunice Monument GB/SA

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"
(FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:	OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>
2. Name of Operator	AMERADA HESS CORPORATION
3. Address of Operator	POST OFFICE DRAWER D, MONUMENT, NEW MEXICO 88265
4. Well Location	Unit Letter <u>E</u> : <u>1980</u> Feet From The <u>NORTH</u> Line and <u>660</u> Feet From The <u>WEST</u> Line

Section <u>2</u>	Township <u>20S</u>	Range <u>36E</u>	NMPM	LEA	County
10. Elevation (Show whether DF, RKB, RT, GR, etc.)					

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
OTHER: <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
	CASING TEST AND CEMENT JOB <input type="checkbox"/>
	OTHER: <input type="checkbox"/>

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Plan to move in and rig up pulling unit. Cut off P&A marker. TIH with tubing, drill collars and bit. Drill out surface plug and clean out to cement plug at 1,882'. TOH with tubing, drill collars and bit. Rig up Schlumberger. Perforate 1,250'-1,251' with 4 JSPP. Rig down Schlumberger. TIH with packer on tubing. Attempt to establish circulation through squeeze holes. TOH with packer. TIH with tubing and cement retainer to $\pm 1,150'$. Clear retainer. Set retainer. Establish circulation with fresh water and obtain rate and pressure. Rig up cementers. Mix and pump approximately 500 sacks Class "C" Neat cement. Obtain circulation and close in surface and intermediate casings to obtain squeeze. TOH with tubing. Spot 10 sack cement plug at surface. Rig down cementers. Rig down pulling unit. Erect P&A marker. Clean and clear location.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Terry L. Harvey TITLE Sr. Staff Assistant DATE 06-07-95

TYPE OR PRINT NAME Terry L. Harvey TELEPHONE NO. 393-2144

(This space for State Use)

ORIGINAL SIGNED BY **JERRY SEXTON**
DISTRICT I SUPERVISOR

APPROVED BY _____ TITLE _____ DATE _____

CONDITIONS OF APPROVAL, IF ANY:

JUN 23 1995

RECEIVED

APR 21 1898
OLD HOBBS
OFFICE

APR 21 1898